

P16LFM00BMB (B)

PROJECTION TELEVISION **VZ4 CHASSIS**

MODEL VS-45501/VS-45502/VS-45501A VS-50501/VS-50502/VS-50501A

:AUTION:

Before servicing this chassis, it is important that the service person read the "SAFETY PRECAUTIONS" AND "PRODUCT SAFETY NOTICE" in this manual.

SPECIFICATIONS

High Voltage :32.0kV (at 0A) :AC 120V, 60Hz Power Input :4" round type 2 pcs. :260W Speaker Power Cabinet :[VS-45501/ 45502/V45501A] Consumption **Dimensions** :39.5"(W) X 49"(H) X 23.4"(D) :VHF 54 ~ 470MHz Frequency :IVS-50501/50502/50501A] Range UHF 470 ~ 806MHz 43.5"(W) X 51.2"(H) X 24.3"(D) Antenna Input :VHF/UHF 75 Ω unbalanced :[VS-45501/45502/45501A] 190 lbs Weight Single axis input [VS-50501/50502/50501A] 195.8 lbs CRT :[VS-45501/45502] [VS-45501A] :VIDEO IN JACK (RCA Type) Input Level 180DLB22 (R) 180DLB22 (R) 1.0Vp-p 75 Ω unbalanced 180DLB22 (G) 180DLB22 (G) : AUDIO IN JACK (RCA Type) 180DLB22 (B) 180DLB22 (B) -3 dBm $43k\Omega$ unbalanced :S-VIDEO IN JACK [VS-50501] [VS-50501A] (Y/C separate type) P16LHV08RJA (R) P16LJK01RJA (R) Y: 1.0 Vp-p C: 0.286Vp-p(BURST) P16LHV08HKA (G) P16LJK01HKA (G) 75 Ω unbalanced P16LHV09BMB (B) P16LJK01BMB (B) :VIDEO OUT JACK (RCA Type) Output Level [VS-50502] 1.0Vp-p 75 Ω unbalanced P16LFM00RFA (R) : AUDIO OUT JACK (RCA Type) P16LFM00HLA (G) -3 dBm 4.7 K Ω unbalanced

- · Weight and dimensions shown are approximate.
- · Design specifications are subject to change without notice.

MITSUBISHI CONSUMER ELECTRONICS AMERICA, INC.

6100 Atlantic Blvd., Norcross, GA. 30071-1305 Copyright © 1997 Mitsubishi Consumer Electronics America, Inc. All Rights Reserved

CONTENTS

INTRODUCTIONSAFETY PRECAUTIONS	3 4
DISASSEMBLY/FRONT AND REAR CABINET COMPONENTS	5
SERVICING PCBsPCB Locations	6
Extension Cord Jigs Table	6
SERVICING OF THE LENTICULAR SCREEN AND FRESNEL LENS	7
Removal of the Lenticular Screen and Fresnel Lens	7 8
CRT REPLACEMENT	10
Removal of the CRT	10
Installation of the CRT	11
Adjustment procedures after replacing the CRT	12
ELECTRICAL ADJUSTMENTS	13
Location of Test Points and Adjustments	14
Initial Set Up	16
Circuit Adjustment Mode	18
When Replacing EEPROM (IC701)	20
List of Adjustment Items	20
Adjustment procedures	24
Multi Channel Sound Circuit	24
High Voltage Control Circuit	25
CRT Circuit	26
Focus Circuit	27
Video Circuit	28
Horizontal and Vertical Deflection Circuits	29
Raster Correction Circuit	30
	31
Screen Character Circuit	
Convergence CircuitPIP Circuit	31 34
CHIP PARTS REPLACEMENT	36
PARTS LIST	37
ELECTRICAL PARTS AND OTHERS	37
LEAD DRESS	46
SIGNAL PATH DIAGRAMS	48
IC BLOCK DIAGRAMS	50

INTRODUCTION

This service manual provides service instruction for PTV Models: VS-45501, VS-45502, VS-45501A, VS-50501, VS-50502 and VS-50501A which use the VZ4 Chassis. Service personnel should read this manual thoroughly before servicing this chassis.

This service manual includes:

- 1. Assembly and disassembly instructions for the front and rear cabinet components
- 2. Servicing of the lenticular screen and fresnel lens.
- 3. Servicing printed circuit boards (PCBs).
- 4. CRT replacement procedure.
- 5. Electrical adjustments.
- 6. Chip parts replacement procedures.
- Lead dress diagram.

The parts list section of this service manual includes:

- 1. Cabinet and screen parts.
- 2. Electrical parts.

Schematic and block diagrams of PTV Models: VS-45501, VS-45502, VS-45501A, VS-50501, VS-50502 and VS-50501A are included in this service manual for better understanding of the circuitry. PCB drawings are also included for easy location of parts and test points.

PRODUCT SAFETY NOTICE

Many electrical and mechanical parts in television receivers have special safety related characteristics. These characteristics are often not evident from visual inspection nor can the protection afforded by them necessarily be obtained by using replacement components rated for higher voltage, wattage, etc.

Replacement parts which have special safety characteristics are identified in this service manual.

Electrical components having such features are identified by shading on the schematic diagram and on the parts list of this service manual, and by marking on the supplementary sheet for this chassis to be issued subsequently. Therefore, the replacement for any safety part should be identical in value and characteristics.

SAFETY PRECAUTIONS

NOTICE:

Observe all cautions and safety related notes located inside the receiver cabinet and on the receiver chassis.

WARNING:

- 1. Operation of this receiver outside the cabinet or with the cover removed presents a shock hazard from the receiver's power supplies. Work on the receiver should not be attempted by anyone who is not thoroughly familiar with the precautions necessary when working on high voltage equipment.
- Do not install, remove or handle the picture tubes in any manner unless shatterproof goggles are worn. People not so equipped should be kept away while the picture tube is being handled. Keep the picture tube away from the body while handling.
- 3. When service is required, observe the original lead dress. Extra precaution should be taken to assure correct lead dress in the high voltage area. Where a short-circuit has occurred, replace those components that indicate evidence of overheating.

B. X-radiation warning

The surface of the cathode ray tubes (CRTs) may generate X-Radiation, so take proper precautions when servicing. It is recommended that a lead apron be used for shielding while handling the CRT. Use this method if possible. When replacing the CRTs, use only the designated replacement part since it is a critical component with regard to X-Radiation. As noted above, no high voltage adjustments are provided. The high voltage specification is described on the cover page.

C. Leakage current check

Before returning the receiver to the customer, it is recommended that leakage current be measured according to the following methods.


1. Cold Check

With the alternating current (AC) plug removed from the AC source, place a jumper across the two AC plug prongs. Connect one lead of an ohm meter to the AC plug and touch the other lead to each exposed metal part (i.e. antennas, handle bracket, metal cabinet, screw heads, metal overlay, control shafts, etc.), particularly any exposed metal part that has a return path to the chassis. The resistance of the exposed metal parts having a return path to the chassis should be a minimum of 1Mega Ohm. Any resistance below this value indicates an abnormal condition and requires corrective action.

2. Hot Check


Use the circuit in Figure 1 to perform the hot check test.

- 1. Keep switch S1 open and connect the receiver to the measuring circuit. Immediately after connection, and with the switching devices of the receiver in their operating positions, measure the leakage current for both positions of switch S2.
- 2. Close switch S1, energizing the receiver. Immediately after closing switch S1, and with the switching devices of the receiver in their operating positions, measure the leakage current for both positions of switch S2. Repeat the current measurements of items 1 and 2 after the receiver has reached thermal stabilization. The leakage current should not be more than 0.5 milliampere (mA).



DISASSEMBLY/ FRONT AND REAR CABINET COMPONENTS

*Refer to PARTS LIST for Part Numbers



Parts Name	Number of Screws
Screen Assy	3
Front Cover	4
Rear Board-1	4
Rear Board-2	2
Back Board	12
Light Box Assy	8

Table 1-2

SERVICING PCBs

PCB Locations




Fig. 3

Extension Cord Jigs Table

When servicing PCBs, use the Extension Cord Jigs for easier access.

PRINTED CIRCUIT BOARD	CONNECTOR	PART NUMBER
DBF	DV (3 PIN)	859C431060
DBF	DW (5 PIN)	859C432060
DBF	DU (7 PIN)	859C431070
PIP	GE (9 PIN), GF (9 PIN)	859C432050
A/V	GB (13 PIN)	859C432030
A/V	GA (11 PIN)	859C432040

^{*} Extension Jigs for servicing of the PCB-Convergence are not listed as the existing leads are of sufficient length.

SERVICING OF THE LENTICULAR SCREEN AND FRESNEL LENS

I. Removal of the Lenticular Screen and Fresnel Lens

A. VS-45501/VS-50501

- 1. Remove the screen assembly as shown in figure 2.
- 2. Remove Frame Holder by removing 12 screws (a).
- 3. Remove Screen Holder by removing 6 screws (b).

Note: When separating the Lenticular Screen from the Fresnel Lens, use caution while prying the Screen and Lens apart using a slot type screw driver, and remove the pressure sensitive, double sided tape.




Figure 4-1

2. Installation of the Lenticular Screen and Fresnel Lens

CAUTION:

WEAR GLOVES WHEN HANDLING THE LENTICULAR SCREEN AND THE

FRESNEL LENS. THIS PREVENTS CUTS AND FINGER PRINTS.

DO NOT PLACE THE FRESNEL LENS IN THE SUN. THIS MAY CAUSE FIRE AND

HEAT RELATED INJURIES.

Note: Store the Lenticular Screen and Fresnel Lens in a cool dry place. High humidity causes deformation of the Lenticular Screen and Fresnel Lens.

A. VS-45501

- 1. Apply double coated tape (Part # LENS-TAPE) along the top front edge of the Fresnel Lens as shown in figure 4-2.
- 2. Place the Fresnel Lens on top of the Lenticular Screen and apply pressure at the top edge to bond them together as shown in figure 4-2.




Figure 4-2

3. Installation of the Lenticular Screen and Fresnel Lens

CAUTION:

WEAR GLOVES WHEN HANDLING THE LENTICULAR SCREEN AND THE FRESNEL LENS. THIS PREVENTS CUTS AND FINGER PRINTS.

DO NOT PLACE THE FRESNEL LENS IN THE SUN. THIS MAY CAUSE FIRE AND

HEAT RELATED INJURIES.

Note: Store the Lenticular Screen and Fresnel Lens in a cool dry place. High humidity causes deformation of the Lenticular Screen and Fresnel Lens.

A. VS-50501

- 1. Apply double coated tape (Part # LENS-TAPE) along the top front edge of the Fresnel Lens as shown in figure 4-3.
- 2. Place the Fresnel Lens on top of the Lenticular Screen and apply pressure at the top edge to bond them together as shown in figure 4-3.




Fig. 4-3

CRT REPLACEMENT

1. Removal of the CRT

CAUTION!


HIGH VOLTAGE SHOULD BE COMPLETELY DISCHARGED PRIOR TO ANODE CAP REMOVAL. SINCE ALL THREE CRTS RECEIVE HIGH VOLTAGE FROM THE FLYBACK TRANSFORMER, DISCHARGE EACH CRT BY SHORTING THE OPEN END OF EACH RESPECTIVE HIGH VOLTAGE CABLE TO CHASSIS GROUND.

Note: Refer to figures 2, and 2-1 when performing steps 1 through 4.

- 1. Remove the Speaker Grille.
- 2. Remove the Front Cover.
- 3. Remove the Screen Assy.
- 4. Remove the Back Board.
- 5. Remove the Anode Lead Wire from the Flyback Transformer.
- 6. Remove the PCB-CRT.
- 7. Remove 4 hex-screws "a" retaining the Optical Unit. [Fig. 5-1]
- 8. Remove 4 screws "b" retaining the Lens.

Note: DO NOT loosen the RED screws. Doing so will break the seal between the C-Element and the # 6 Lens, causing leakage of the CRT Coolant.

- 9. Remove 4 screws "c" retaining the CRT. [Fig. 5-2]
- 10. Remove the Deflection Yoke from the neck of the CRT. [Fig. 5-7]



PAGE 10

INSTALLATION OF THE CRT

Note: The replacement CRT is supplied as an assembly comprised of the CRT and the Inner Lens with the space between them filled with ethylene glycol. Care should be taken during handling and installation to prevent shock from disrupting the seal or alignment between the CRT and Inner Lens. [Fig. 5-3]





Fig 5-3

Note: The CRT fixing screws should not be loosened nor should they be removed. [Fig. 5-4]



1. Carefully position the replacement CRT and fasten in place using 4 screws "d" shown in Fig. 5-6.




Fig 5-5

PAGE 11




Fig 5-6

- 2. Install the Deflection Yoke on the CRT neck. [Fig. 5-7]
- 3. Install the Lens that was removed in steps 8 and 9 of Removal Of The CRT. [Figs. 5-1 and 5-2]
 - a) Position the Lens so that the Label faces the direction shown in Fig. 5-8.
 - b) Install the mounting screws. Refer to Fig. 5-1.
- 4. Install the PCB-CRT.
- 5. Insert the Optical Unit into the Light Box Assembly.
- 6. Insert the Anode Lead Wire into the Flyback Transformer.
- 7. Re-clamp the Lead Wire in its original position.

Note: Refer to Lead Dress Diagrams pages 46-47.




Fig 5-7




Fig 5-8

Adjustment procedures after replacing the CRT(s)

CRT Cut Off / White Balance Adjustment Static Convergence Adjustment Dynamic Convergence Adjustment

ELECTRICAL ADJUSTMENTS

Note:

Perform only the adjustments required.

Do not attempt an alignment if proper equipment is not available.

1. Measuring Equipment and Jigs

- Oscilloscope (Unless otherwise specified, use 10:1 probes)
- * Signal Generator
- * Frequency Counter
- * Direct Current Voltmeter
- * Sweep Generator.
- * Direct Current Power Supply
- * Multiplex Audio Signal Generator
- * Direct Current Ampere Meter

2. Test Signal

A. Monoscope Signal

Note: Connect the unit to a VCR and play an *alignment tape (Monoscope), if you do not have a monoscope signal source for

adjustment.


(* Part Number: 859C568020)

GRADATION SCALE

B. Color Bar Signal


Use the color bar signal shown below, unless otherwise specified in this manual.

Monoscope Signal




3. Location of Test Points and Adjustments


PCB-MAIN (COMPONENT SIDE)




PCB-SIGNAL (COMPONENT SIDE)




PCB-PIP/APT (COMPONENT SIDE)




PCB-CRT (R) (COMPONENT SIDE)



PCB-CRT (G) (COMPONENT SIDE)



PCB-CRT (B) (COMPONENT SIDE)



4. Option Menu Set Up

Follow the steps below for the Option Menu set up:

- 1. Set the receiver to the "TV" mode.
- 2. Select the "MENU" display by pressing the "MENU" button once.
- 3. Press the number buttons "2", "3", "5", "8" in sequence to select the "Option Menu" display.
- 4. Set the "Option Menu" as shown in the table below using the "ADJUST" and "ENTER" buttons.
- 5. Press the "MENU" button twice to return to normal viewing.

Option Menu

Initial	
Hotel	: OFF
Power Restore	: OFF
Antenna	: 2
Input	: 3
When Muting	: ON
Firmware Version Number	

Initial Settings

Initial Item	Initial Setting	Initial Item	Initial Setting
INPUT RECEIVING CH TV / CATV Q.V. CHANNEL MEMORY TV Lock Channel Lock LOCK CODE VOLUME AUDIO FUNCTIONS Listen To Bass Treble Balance Surround Speaker Monitor Out Level Sound VIDEO FUNCTIONS TV IRIS Tint Color Contrast Brightness Sharpness Color Temp Background TV Instant Info	TV CH OO3 CATV CH 003 ALL CH (0.0) OFF OFF 30% STEREO 50% 50% 50% OFF ON Variable OFF OFF 50% 50% 50% 100% 50% 50% High Gray ON	TV CC PIP SOURCE PIP POSITION VIDEO MUTE NAME THE INPUT S.Q.V. AUTO CLOCK A/V NETWORK SELECT LANGUAGE NAME THE CHANNEL SELECT MENU TYPE Parental Lock	When Muting TV Lower Right OFF ALL LABELS CLEAR ALL CH CLEAR ON OFF English ALL LABELS CLEAR Standard Menu Cancel

5. Service Menu Set Up

Follow the steps below for the initial set up:

- 1. Select the "MENU" display by pressing the "MENU" button once.
- 2. Press the number buttons "1", "3", "7", "0" in sequence to select the "SERVICE MENU" display.
- 3. Press the "ADJUST" button to select "Initial."
- 4. Press "ENTER."

NOTE:

At this time channel 3 is automatically selected.

CAUTION:

DO NOT ACTIVATE E2 RESET AS THIS WILL RESET ALL ALIGNMENT DATA.

Service Menu

Initial			
E2 RESET		3 Dia:	On
Hotel:	Off	Auto Clock:	On
Power Restore:	Off	Guide Plus:	Off
Antenna:	2		
Input:	3		
When Muting:	On		
Firmwar	e Version N	umber 🔲 🗌	

5. Circuit Adjustment Mode

Except for the following, all adjustment items must be performed using the remote hand unit.

Adj. Item	Description
6	Lens Focus
7	Electrostatic Focus

A. Activating the Circuit Adjustment Mode

- 1. Press the "MENU" button on a remote hand unit. (The "MENU" display will appear.)
- 2. Press the number buttons "2", "3", "5", "7" in sequence. (The screen will change to the circuit adjustment mode.)


Note: Repeat steps 1 and 2 if circuit adjustment mode does not appear on screen.

B. Selection of adjustment Functions and Adjustment Items

To select an adjustment item in the circuit adjustment mode, first select the adjustment function that includes the specific adjustment item to be selected. Then, select the adjustment item.

Refer to the following pages for the listing of adjustment functions and adjustment items.


 Press the "AUDIO" button on a remote hand unit to select an adjustment function. Each time the button is pressed, the adjustment function changes in the following sequence.




Press the "VIDEO" button to select a specific adjustment item. The adjustment item number increases each time the "VIDEO" button is pressed.

C. Changing data

After selecting an adjustment item, use the 'ADJUST" button to change the adjustment data.





D. Saving Adjustment Data

Press "ENTER" to save the adjustment data in memory. The character display turns red for approximately one second in this step.

Note: If the circuit adjustment mode is terminated without pressing the "ENTER" button, changes in adjustment data are not saved (with the exception of PIP adjustments).

E. Terminating the Circuit Adjustment Mode

Press the "MENU" button on the remote hand unit twice to terminate the circuit adjustment mode.

Note: The circuit adjustment mode can also be terminated by turning the power off.

When Replacing the EEPROM (IC701)

The EEPROM (IC701) stores the adjustment data. After replacing the EEPROM, readjust the data to the values given in the following tables. If good performance is not obtained with these values, perform the Adjustment Procedure(s) given in the Note column.

List of Adjustment Items

Function	Display	VCJ			IC200
Item Number		Adjustment Name	Range	Initial Data	Note
		PICTURE GAIN CONTROL	0~63	42	
0	CON	TINT CONTROL 1	0~63	31	
1	TNT	COLOR GAIN CONTROL 1	0~63	31	
2	COL	BRIGHT LEVEL CONTROL 1	0~63	31	
3	BRT	SHARPNESS GAIN CONTROL	0~15	6	
4	SHP CTG	G CUT-OFF ADJ.	0~15	7	#4 (CRT Cut Off, White Balance)
5 6	CTB	B CUT-OFF ADJ.	0~15	7	#4 (CRT Cut Off, White Balance)
7	DRG	G DRIVE GAIN ADJ.	0~63	42	#4 (CRT Cut Off, White Balance)
8	DRB	B DRIVE GAIN ADJ.	0~63	42	#4 (CRT Cut Off, White Balance)
9	LDG	LOW GREEN DRIVE GAIN	0~63	20	#4 (CRT Cut Off, White Balance)
10	LDB	LOW BLUE DRIVE GAIN	0~63	20	#4 (CRT Cut Off, White Balance)
11	YDL	Y CHROMA TRAP	0~1	0	·
12	VM	Y OUTPUT FOR VM	0~1	0	
13	DCT	SW OF DC PROPAGATED RATE	0~1	1	
14	DPC	SW OF BLK LEVEL EXPANSION	0~1	1	
15	TOT	SW OF CHROMA TOT FILTER	0~1	0	
16	AXS	SW OF R-Y, G-Y AXIS	0~1	1	
17	DCO	SW OF DYNAMIC COLOR	0~1	1	
18	ABL	SW OF ABL MODE	0~1	0	
19	DL1	RATIO OF PRE/OVER-SHOOT	0~3	0	
20	DL2	SHARPNESS FO CONTROL	0~3	1	
21	SCN	CONTRAST GAIN CONTROL	0~15	3	
22	CTA	CHROMA TRAP FO ADJ.	0~15	7	
23	SCL	COLOR GAIN CONTROL	0~15	2	İ
24	SHU	TINT CONTROL	0~15	10	
25	SBR	BRIGHT LEVEL CONTROL	0~63	31	#10 (Black Level)
26	GMG	GAMMA CONTROL	0~3	2	
27	AG1	AGING MODE - WHITE OUTPUT	0~1	0	
28	AG2	AGING MODE - BLACK OUTPUT	0~1	0	
29	RON	R VIDEO OUTPUT	0~1	1	
30	GON	G VIDEO OUTPUT	0~1	1	
31	BON	B VIDEO OUTPUT	0~1	1	
32	PON	RGB VIDEO OUTPUT	0~1	1	
33	VOF	SW OF V-SAW OSCILLATION	0~1	1	
35	CMD	SW OF V COUNTDOWN	0~1	0	
37	VHT	VERTICAL HEIGHT	0~63	21	
40	AFC	AFC LOOP GAIN	0~3	1	
41	VSC	ADJ OF VERT S-CORRECTION	0~15	7	#9 (Vertical Linearity)
42	VLR	VERT LINEARITY ADJ.	0~15	7	#9 (Vertical Linearity)
44	RPO	REFERENCE PULSE TIMING	0~3	3	
47	HPS	HORIZ POSITION ADJ.	0~15	5	
51	ABW	VERT BOW CORRECTION	0~15	7	
52	AAG	VERT TILT CORRECTION	0~15	7	
55	HBL	H BLK ON SOFT-FULL MODE	0~1		
61	LBK	H BLK OF LEFT SIDE	0~15	9	
62	RBK	H BLK OF RIGHT SIDE	0~15	12	#7 (Sub Contract)
69	SCT	PICTURE CONTROL	0~63	42	#7 (Sub Contrast)
70	ESY	*FACTORY SET-UP ONLY*	0~1	0	
71	CD2	*FACTORY SET-UP ONLY*	0~1	0	·

Function	Display	PIP			IC7001
ltem Number	Abbreviated Name	Adjustment Name	Range	Initial Data	Note
0	CONT	CONTRAST	0~127	48	#18 (PIP Contrast)
1	COLR	COLOR OUTPUT GAIN	0~127	34	#16 (PIP Chroma Gain)
2	TINT	TINT	0~63	28	#17 (PIP Sub Tint)
3	BRIT	BRIGHTNESS	0~31	15	
4	EMPH	EMPHASIS	0~1	1	
5	DECD	DECODE	0~1	0	,
6	SYNC	SYNC LEVEL	0~3	3	
7	RVS	GREY BACKGROUND	0~1	0	
8	RVHS	FREE RUN CONTROL	0~1	0	
9	BG-Y	BACKGROUND LUMINANCE	0~16	12	
10	BSTB	BURST GAIN BLUE	0~255	76	
11	BSTR	BURST GAIN RED	0~255	145	
12	MVW	MACROVISION	0~255	0	
13	CRTN	FIXED DATA	0~3	3	
14	VXA	VERTICAL POSITION	0~255	145	
15	VXS	VERTICAL SAMPLING POSITION	0~63	41	
16	HXA0	HORIZONTAL POSITION	0~255	97	
17	ADJ	HORIZONTAL DELAY	0~3	4	
18	YDL	SUB Y DELAY	0~255	4	
19	HPX	SAMPLING STARTING POSITION	0~63	3	
20	VYA9 HYA9	SUB VERTICAL WIDTH (1/9)	0~255	68	
21	VYA6	SUB HORIZONTAL WIDTH (1/9) SUB VERTICAL WIDTH (1/6)	0~63	56	
23	HYA6		0~255 0~63	51	
24	BGBY	SUB HORIZONTAL WIDTH (1/6) B-Y GAIN	0~63	4 2 4	
25	BGRY	R-Y GAIN	0~7	4	
26	CHRO	CHROMA ALIGNMENT	0~63	63	
27	EXTP	EXTENSION PORT	0~3	2	
28	BGPM	BURST GATE PULSE	0~1	1	
29	HX	SAMPLING START POSITION	0~63	22	
30	EXSY	ANALOG SYNC SEPARATOR	0~3	2	
31	LPF	LOW PASS FILTER	0~3	2	
32	внѕ9	EXT/INT SYNC (1/9)	0~3	3	
33	BHS6	EXT/INT SYNC (1/6)	0~3	3	
34	HADJ	BGP POSITION	0~16	15	
35	BGST	BGP PHASE SETTING	0~63	14	
36	EXHD	EXT HD	0~3	0	
37	EXVD	EXT VD	0~1	0	
38	PN28	PIN 28 OUTPUT	0~63	1	
39	BGPX	BURST GATE PULSE OUTPUT ALIGNMENT	0~63	29	
40	BGPY	COLOR SATURATION ALIGNMENT	0~63	63	
41	BPF1	BANDPASS FILTER	0~3	0	
42	TACC	TEST ACC LEVEL	0~63	0	
43	ACC	ACC LEVEL	0~63	21	
44	FSC	*FACTORY ADJUSTMENT ONLY*	0~3	0	
				i	

Function Display	HR			
Adjustment Name		Range	Data	Note
Character Position		0~25	20	#12 CHR POS.

Function	Display	MCS			
ltem Number	Abbreviated Name	Adjustment Name	Range	Initial Data	Note
0	INP	INPUT LEVEL ADJ	0~15	7	#1 (Input Level)
1	AUT	STEREO ADJ	0~1	0	
2	WDE	SPECTRAL WIDE	0~31	16	
3	SPC	SPECTRAL EXPANSION	0~31	16	
4	ATK	ATTACK TIME FOR AVL	0~3	1	#1 (Input Level)
5	VZX	ZERO CROSS VOLUME	0~1	1	#1 (Input Level)
6	MZX	ZERO CROSS MUTE	0~1	1	#1 (Input Level)

Function	Display VDRV			IC870	
ltem Number	Abbreviated Name	Adjustment Name	Range	Initial Data	Note
0 1 2 3 4	PCON PFOC WCON WFOC PLL	CONVERGENCE PHASE FOCUS PHASE CONVERGENCE PULSE WIDTH FOCUS PULSE WIDTH PLL DIVIDING RATIO	0~255 0~255 0~63 0~63 0~15	128 0 33 44 5	DISPLAY ONLY DISPLAY ONLY #14 (Dynamic Convergence)

Function	Display	HV			
Item Number		Adjustment Name	Range	Initial Data	Note
0	ΗV	HIGH VOLTAGE CONTROL	0~254	150	#3 (HV Control)

Function	Display	Al				
ltem Number	Abbreviated Name	Adjustment Name	Range	Initial Data	Note	
0	OT1	*AUTO IRIS*	0~255	60		
1	IT2		0~255	140		
2	CN0	FACTORY	0~63	02		
3	CN1	ADJUSTMENT	0~63	07		
4	CN2	ADJUSTMENT	0~63	63		
5	BR0	ONLY	0~63	28		
6	BR1		0~63	30	i	
7	BR2		0~63	31		

Function	Display	CONV GEO			IC8G00
Item Number	Abbreviated Name	Adjustment Name	Range	Data	Note
0	HWID	HORIZ WIDTH	0~254	127	#10 (Horizontal Width)
1	TILT	TILT	0~254	127	#11 (Raster Correction)
2	VBOW	VERT BOW	0~254	127	#11 (Raster Correction)
3	SKEW	SKEW	0~254	127	#11 (Raster Correction)
4	HBOW	HORIZ BOW	0~254	127	#11 (Raster Correction)
5	TBPC	TOP/BOTTOM PIN CUSHION	0~254	127	#11 (Raster Correction)
6	EWPC	EAST/WEST PIN CUSHION	0~254	127	#11 (Raster Correction)
7	VIPC	VERT INSIDE PIN CUSHION	0~254	127	#11 (Raster Correction)
8	HIPC	HORIZ INSIDE PIN CUSHION	0~254	127	#11 (Raster Correction)
9	HKEY	HORIZ KEYSTONE	0~254	127	#11 (Raster Correction)
10	VKEY	VERT KEYSTONE	0~254	127	#11 (Raster Correction)
11	VSBW	VERT SIDE BOW	0~254	127	#11 (Raster Correction)
12	VSTL	VERT SIDE TILT	0~254	127	#11 (Raster Correction)
13	V3RD	VERT 3RD CORRECTION	0~254	127	#11 (Raster Correction)
14	V4TH	VERT 4TH CORRECTION	0~254	127	#11 (Raster Correction)
15	HSBW	HORIZ SIDE BOW	0~254	127	#11 (Raster Correction)
16	HSKW	HORIZ SIDE SKEW	0~254	127	#11 (Raster Correction)
17	H3RD	HORIZ 3RD CORRECTION	0~254	127	#11 (Raster Correction)
18	HSSS	HORIZ SIDE S CORRECTION	0~254	127	#11 (Raster Correction)
19	HLIN	HORIZ LINEARITY	0~254	127	#11 (Raster Correction)
20	HSLN	HORIZ SIDE LINEARITY	0~254	127	#11 (Raster Correction)

	unction Display CONV					Red: IC8D00 Blue: IC8E00	
Item	1	Abbreviated	Adjustment Name Range Data		Data	Note	
Num	ber	Name					
Red	Blue						
0	30 I	HSTA	HORIZ STATIC	0~254	127	#14 (Dynamic Convergence)	
1	31	VSTA	VERT STATIC	0~254	127	#14 (Dynamic Convergence)	
2	32	TILT	VERT TILT	0~254	127	#14 (Dynamic Convergence)	
3	33	вом	VERT BOW	0~254	127	#14 (Dynamic Convergence)	
4	34	SKEW	SKEW	0~254	127	#14 (Dynamic Convergence)	
5	35	нвом	HORIZ BOW	0~254	127	#14 (Dynamic Convergence)	
6	36	VWID	VERT HEIGHT	0~254	127	#14 (Dynamic Convergence)	
7	37	VLIN	VERT LINEARITY	0~254	127	#14 (Dynamic Convergence)	
8	38	HWID	HORIZ WIDTH	0~254	127	#14 (Dynamic Convergence)	
9	39	HLIN	HORIZ LINEARITY	0~254	127	#14 (Dynamic Convergence)	
10	40	HSDL	LEFT HORIZ SIDE	0~254	127	#14 (Dynamic Convergence)	
11	41	HSDR	RIGHT HORIZ SIDE	0~254	127	#14 (Dynamic Convergence)	
12	42	SLIN	HORIZ LIN MIDDLE (1)	0~254	127	#14 (Dynamic Convergence)	
13	43	CLIN	HORIZ LIN MIDDLE (2)	0~254	127	#14 (Dynamic Convergence)	
14	44	VKLU	VERT KEYSTONE (L-UPPER)	0~254	127	#14 (Dynamic Convergence)	
15	45	HKLU	HORIZ KEYSTONE (L-UPPER)	0~254	127	#14 (Dynamic Convergence)	
	46	VKLL	VERT KEYSTONE (L-LOWER)	0~254	127	#14 (Dynamic Convergence)	
17	47	HKLL	HORIZ KEYSTONE (L-LOWER)	0~254	127	#14 (Dynamic Convergence)	
18	48	VKRL	VERT KEYSTONE (R-LOWER)	0~254	127	#14 (Dynamic Convergence)	
19	49	HKRL	HORIZ KEYSTONE (R-LOWER)	0~254	127	#14 (Dynamic Convergence)	
20	50	VKRU	VERTKEYSTONE (R-UPPER)	0~254	127	#14 (Dynamic Convergence)	
	51	HKRU	HORIZ KEYSTONE (R-UPPER)	0~254	127	#14 (Dynamic Convergence)	
	52	LHBW	HORIZ SLOPING ENDS (LEFT)	0~254	127	#14 (Dynamic Convergence)	
	53	RHBW	HORIZ SLOPING ENDS (RIGHT)	0~254	127	#14 (Dynamic Convergence)	
24	54	LVBW	VERT SLOPING ENDS (LEFT)	0~254	127	#14 (Dynamic Convergence)	
	55	RVBW	VERT SLOPING ENDS (RIGHT)	0~254	127	#14 (Dynamic Convergence)	
	56	DA42	KEYSTONE OFFSET	0~254	127	#14 (Dynamic Convergence)	
- 1	57	DA50		0~254	127	Display Only	
	58	DA51		0~254	127	Display Only	
29	59	DA52		0~254	127	Display Only	
	İ				· <u>-</u> ·		
		i		<u> </u>		<u></u>	

circuit.

Adjustment purpose

10.

Symptom when 1. Input Level incorrectly adjusted Measuring Oscilloscope Instrument Test Point 3. Connector "JR" pin 2 Exit Trigger Measurement DIV 50mV range TIME 2ms RF signal Input Signal (Monaural Sound) Input Terminal RF IN terminal 9.

MULTI CHANNEL SOUND

CIRCUIT]

- 1. Supply an RF signal (monaural sound 400Hz 100% MOD).
- 2. Connect the oscilloscope to connector "JR" pin 2.
- B. Press the "MENU" button on a remote hand unit.
- 4. Press the numerical buttons 2-3-5-7 in sequence to change the screen to the circuit adjustment mode.

Distorted sound during an MCS broadcast.

- 5. Set the adjustment function to "MCS" by pressing the "AUDIO" button.
- Initialize adjustment values to those shown in the table below by pressing the "VIDEO" and "ADJUST" buttons.
- 7. Select adjustment item "0 INP" using the "VIDEO" button.
- 8. Set the adjustment data so that the amplitude is 500 \pm 20 mVrms (1.41 \pm 0.05Vp-p)
 - Press "ENTER" to write the adjustment data into memory.
 - Press the "MENU" button twice to terminate the circuit adjustment mode.


Set the level of the input signal for the multi channel sound

Note: Adjustment item 2 (Stereo Separation) must be performed after

this adjustment.

Adjustment Abbreviated Name	Initial Data
0 INP	7
1 AUT	0
2 WDE	16
3 SPC	16
4 ATTK	1
5 VZX	1
6 MZX	1

PCB-SIGNAL (COMPONENT SIDE)



[MULTI CHANNEL SOUND | Adjustment purpose Adjust right and left separation. CIRCUIT]

2. Separation


Symptom when incorrectly adjusted

Poor or no stereo separation.

Oscilloscope
Connector "JR" pin 2
Division 10mV Time 2ms
RF signal (Stereo Sound)
RF IN terminal

- Note: This adjustment must follow item 1 (Input Level)
- 1. Supply an RF signal (L-CH stereo sound 300Hz 30% MOD).
- 2. Connect the oscilloscope to connector "JR" pin 2.
- 3. Press the "MENU" button on a remote hand unit.
- Press the numerical buttons 2-3-5-7 in sequence to change the screen to the circuit adjustment mode.
- 5. Set the adjustment function to "MCS" by pressing the "AUDIO" button.
- 6. Make sure that the value of item"3 SPC" is 16.
- 7. Select adjustment item "2 WDE" using the "VIDEO" button
- 8. Using the "ADJUST" button, set the adjustment data so that the amplitude of the 300Hz waveform is at minimum.
- 9. Change the modulation fequency to 3kHz.
- 10. Select adjustment item "3 SPC" using the "VIDEO" button.
- 11. Using the "ADJUST" button, set the adjustment data so that the amplitude of the 3kHz waveform is at minimum.
- 12. Repeat steps 7 and 8.
- 13. Press "ENTER" to write the adjustment data into memory.
- 14. Press the "MENU" button twice to terminate the circuit adjustment mode.

PCB-SIGNAL (COMPONENT SIDE)



MODEL:VS-45501/VS-45502/VS-45501A/VS-50501/VS-50502/VS-50501A Adjustment purpose [High Voltage Circuit] CRT anode voltage. Symptom when 3. High Voltage Control Too dark picture. incorrectly adjusted Measuring Note: This adjustment must follow item 4 (CRT Cut OFF, White Balance). DC Voltmeter Instrument Set the CONTRAST control to maximum and BRIGHTNESS - Lead: pin 1 of connector DQ control to center position .. Test Point + Lead: pin 2 of connector DQ Supply a VIDEO signal (monoscope). Exit Trigger Observe the DC voltage between pins 1 and 2 of connector DQ. (positive lead to pin 2). Measurement Press the "MENU" button on a remote hand unit. range Press the numerical buttons 2-3-5-7 in sequence to change the VIDEO signal screen to the circuit adjustment mode. Input Signai (Monoscope) 5. Set the adjustment function to "HV" by pressing the "AUDIO" VIDEO IN terminal Input Terminal 6. Select the adjustment item "0 HV" using the "VIDEO" button. Set the adjustment data so the DC voltmeter reads 0.15 \pm 0.005V 7. using the "ADJUST" button. PCB-MAIN (COMPONENT SIDE) Press "ENTER" to write the adjustment data into memory. 8. Press the "MENU" button twice to terminate the circuit adjustment 000 10. Confirm the voltage at DQ pin 2 does not exceed 0.85V. DQ If voltage exceeds this limit, repeat adjustment procedure. 11. T5A03

4. CRT Cut Off,	Symptom incorrectly	
Measuring Instrument	DC Ammeter Oscilloscope	
Test Point	TP6R/G/B	
Exit Trigger		
Measurement Range	Division 5V Time 2ms	
Input Signal		
Input Terminal		_

[CRT Circuit]


ctly	adjusted								
	when	Monochrome	with	color	tint,	or	incorrect	brightnes	SS.

Adjustment purpose

To set the cut off point of the three CRTs

- Select the EXT-1 input with no signal supplied. 1.
- Press the "MENU" button on a remote hand unit. 2.
- Press the numerical buttons 2-3-5-7 in sequence to change the 3. screen to the circuit adjustment mode.
- Set the adjustment function "VCJ " by pressing the "AUDIO"
- Set the items shown in the Table to the given data values. 5.
- Observe the waveform at TP6R. 6.
- Adjust the SCREEN control (R) so that the voltage is 200V. 7.
- 8. Observe the waveform at TP6G.
- Adjust the SCREEN control (G) so that the voltage is 200V. 9.
- Observe the waveform at TP6B. 10.
- Adjust the SCREEN control (B) so that the voltage is 200V.


Abt N a	me	Data
3	BRT	31
5	CTG	7
6	СТВ	7
7	DRG	42
8	DRB	42
25	SBR	31



- 12. Supply a VIDEO signal (full white raster)
- 13. Set adjustment data of "7 DRG" and "8 DRB" so that the white level is optimum at the center of the screen.
- 14. Observe the waveform at "TP6G".
- 15. Set the data of "5 CTG" so that the voltage is 200V.
- 16. Observe the waveform at "TP6B".
- 17. Set the data of "6 CTB" so the the voltage is 200V.
- 18. Measure the DC current as indicated in Table 1.

Note: The internal resistance of the ammeter must be 30 Ω or less, and the length of the lead wires should be 12 inches or less. Measure the current in the three CRTs at the same time. Make sure that the current in the GREEN and BLUE CRTs does not exceed the values shown in Table 2. If excessive, readjust the current to the approximate values given in Table 3 and repeat steps 1-18.

- 19. Press "ENTER" to write the adjustment data into memory.
- 20. Press the "MENU" button twice to terminate the circuit adjustment mode.



FRONT VIEW

	Connections of Ampere Meter		
	Positive	Negative	
R G B	R6R0 (+ SIDE) R6G0 (+ SIDE) R6B0 (+SIDE)	R6R0 (- SIDE) R6G0 (- SIDE) R6B0 (- SIDE)	

Table 1

	Maximum Current
G	580μΑ 530μΑ
В	530μΑ

Table 2

Current Proportion					
R	R G				
225μΑ	540μΑ	485μΑ			


Table 3

Adjustment purpose

when

adjusted

[Focus Circuit]		Adjustment purpose		ırpose
5. Lens Focus	5	Sympto: incorrec		
Measuring Instrument			Note:	This ac
Test Point			1.	<i>monoci</i> Supply
Exit Trigger			2.	Produc a) Pres
Measurement range				b) Pres
Input Signal	VIDEO signal (Monoscope)		3.	Adjust 1
Input Terminal	VIDEO IN terminal			L f




The best resolution of the picture.

1. Supply a VIDEO signal (monoscope).

Blurred picture.

- Produce a GREEN monochrome picture.
 - a) Press the "MENU" button on a remote hand unit.
 - b) Press the buttons 2-3-5-9 then press the button specified in the table below to select each color.
- Adjust the position of the lens for the best picture resolution. NOTE: Attach a white paper to the inside center of the screen. During adjustment, observe the picture on the screen from inside for easier adjustment.
- Display the original picture and press "MENU" twice.



Monochrome Picture	Remote Hand Unit Button
RED	1
GREEN	2
BLUE	3

		Symptom incorrect		
Measuring Instrument			No	
Test Point				
Exit Trigger			1. 2.	
Measurement range			3.	
Input Signal	VIDEO signal (Monoscope)			
Input Terminal	VIDEO IN terminal		4.	

[Focus Circuit]

Focus Pack (SCREEN VR) FRONT VIEW

Note: This adjustment must follow item 7 (Sub Contrast). If you replace the CRT, this adjustment must follow item 5, (Lens Focus). Perform this adjustment respectively for RED, GREEN, and BLUE monochrome pictures.

For best resolution of the picture.

1. Supply a VIDEO signal (monoscope).

Out of focus picture.

- 2. Press the "A/V RESET" button in the control panel to reset all VIDEO FUNCTIONS.
- Produce a monochrome picture. 3.
 - a) Press the "MENU" button on a remote hand unit.
 - b) Press the buttons 2-3-5-9 then press the button specified in the table below to select each color.
 - Adjust the FOCUS VR on the focus pack so the sharpness of the upper area of the screen is optimum.
- 5. Display the original picture and press "MENU" twice.

Monochrome Picture	Remote Hand Unit Button
RED	1
GREEN	2
BLUE	3


Video Circuit]	Adjustment purpose To set the beam current to its optimum value.
7. Sub Contra	1	Symptom when Excessive or insufficient contrast. incorrectly adjusted
Measuring nstrument	DC Milliammeter	Note: This adjustment must follow item 4 (CRT Cut-Off, White Balance). Preheat the set for two minutes or more.
est Point	+ Lead: pin 3 of cor - Lead: pin 1 of con	nector MS 2. Press the "MENU" button on a remote hand unit.
xit Trigger		3. Press the numerical buttons 2-3-5-7 in sequence to change the screen to the circuit adjustment mode. 4. Set the adjustment function "VCJ" by pressing the "AUDIO" button.
Measurement ange	3mA	5. Select the adjustment item "69 SCT" using the "VIDEO" button. 6. Measure the current at pins 1 and 3 of connector MS (Plus lead to pin 3)
nput Signal	RF signal (Gray scale 87.5%	7 Sot the adjustment data so the DC milliammeter reads 725 ± 25µA
nput Terminal	RF IN terminal	9. Press the "MENU" button twice to terminate the circuit adjustment mode
MS	T5A03 F.B.T.	
[Video Cine	<u> </u>	Adjustment purpose Picture Luminance.
[Video Circui		Symptom when Excessive or insufficient brightness.
_		incorrectly adjusted
8. Black Leve		Note: This adjustment must follow item 7 (Sub-Contrast). 1. Supply an VIDEO signal (monoscope).
8. Black Leve		Note: This adjustment must follow item 7 (Sub-Contrast). 1. Supply an VIDEO signal (monoscope). 2. Press the "MENU" button on a remote hand unit. 3. Press the numerical buttons 2-3-5-7 in sequence to change the
8. Black Leve Measuring Instrument Test Point		Note: This adjustment must follow item 7 (Sub-Contrast). 1. Supply an VIDEO signal (monoscope). 2. Press the "MENU" button on a remote hand unit. 3. Press the numerical buttons 2-3-5-7 in sequence to change the screen to the circuit adjustment mode. 4. Set the adjustment function "VCJ" by pressing the "AUDIO" button.
8. Black Leve Measuring Instrument Test Point Exit Trigger Measurement		Note: This adjustment must follow item 7 (Sub-Contrast). 1. Supply an VIDEO signal (monoscope). 2. Press the "MENU" button on a remote hand unit. 3. Press the numerical buttons 2-3-5-7 in sequence to change the screen to the circuit adjustment mode. 4. Set the adjustment function "VCJ" by pressing the "AUDIO" button. 5. Select the adjustment item "25 SBR" using the "VIDEO" button. 6. Observe the gradation pattern inside a monoscope signal, and set the
8. Black Leve Measuring Instrument Test Point Exit Trigger Measurement range		Note: This adjustment must follow item 7 (Sub-Contrast). 1. Supply an VIDEO signal (monoscope). 2. Press the "MENU" button on a remote hand unit. 3. Press the numerical buttons 2-3-5-7 in sequence to change the screen to the circuit adjustment mode. 4. Set the adjustment function "VCJ" by pressing the "AUDIO" button. 5. Select the adjustment item "25 SBR" using the "VIDEO" button.

 40%
 30%
 20%
 10%

 50%
 0%
 0%
 0%

 60%
 70%
 80%
 90%

GRADATION SCALE



Adjustment purpose

Adjustment purpose


adjusted

Symptom when

adjusted

9. Vertical Linearity, Height | Symptom when and S-Correction incorrectly Measuring Instrument Test Point Exit Trigger Measurement rande VIDEO signal Input Signal (Monoscope) Input Terminal VIDEO IN terminal

[Deflection Circuit]



Supply a VIDEO signal (monoscope)

To set vertical linearity.

2. Press the "MENU" button on a remote hand unit.

Incorrect vertical height and linearity.

- 3. Press the numerical buttons 2-3-5-7 in sequence to change the screen to the circuit adjustment mode.
- 4. Set the adjustment function to "VCJ" by pressing the "AUDIO" button.
- Select adjustment item "47 VHT" using the "VIDEO" button. Adjust so that the vertical markers are equal using the "ADJUST" button.
- 6. Select the adjustment item "42 VLR" using the "VIDEO" button
- 7. Set the adjustment data so that the largest circle is round using the "ADJUST" button.
- 8. Supply a VIDEO signal (crosshatch).
- Select the adjustment item "41 VSC"(Vertical S) using the "VIDEO" 9. button.
- 10. Set the adjustment data so that the height of the squares in the cross hatch signal are equal at the top, bottom and middle of the screen using the "ADJUST" button.
- 11. Press "ENTER" to write the adjustment data into memory.
- 12. Press the "MENU" button twice to terminate the circuit adjustment mode.

101 110112011		incorrecti
Measuring Instrument		
Test Point		
Exit Trigger		
Measurement range		
Input Signal	VIDEO signal (Monoscope)	
Input Terminal	VIDEO IN termina	al

[Deflection Circuit]

10. Horizontal Width


Note: This adjustment must follow item 4 (CRT Cut Off, White Balance) and item 3 (High Voltage Control). Perform this adjustment alternately with item 11 (Raster Distortion Correction).

Picture compressed or expanded horizontally.

- 1. Supply a VIDEO signal (monoscope).
- Cover the RED and BLUE lenses, producing a GREEN monochrome picture.
- Press the "MENU" button on a remote hand unit. 3.


To set the width of the picture.

- Press the numerical buttons 2-3-5-7 in sequence to change the screen to the circuit adjustment mode.
- 5. Set the adjustment function to "CONV GEO" by pressing the "AUDIO"
- 6. Select the adjustment item "0 HWID" using the "VIDEO" button.
- 7. Set the adjustment data so the sum of the horizontal width markers is 6.0 using the "ADJUST" button.
- Press "ENTER" to write the adjustment data into memory.
- Press the "MENU" button twice to terminate the circuit adjustment mode.



[Raster Correction Circuit]	Adjustment purpose	To correct picture distortion).
11. Raster Correction	Symptom when incorrectly adjusted	Distorted picture.	
Measuring Instrument Test Point Exit Trigger Measurement Range Input Signal (Crosshatch) Input Terminal VIDEO IN terminal	2. Cover the 3. Press the 4. Press the (The scree 5. Set the fun 6. Set the dat vertical line 7. Write the d 8. Terminate NOTE: Adju imm	TIDEO signal (Crosshatch) RED and BLUE lenses, producing MENU" button on a remote hand buttons 2-3-5-7 in sequence. In will change to the circuit adjus action to "CONV GEO." ("AUDIO" at of the items below so that all the estate straight and spacing is line ata into memory. (Press "ENTER the circuit adjustment mode. (Pre ausment 14 (Dynamic Convergent mediately after this adjustment.	unit. tment mode.) button) he green horizontal and ear. ") ess "MENU" twice)
		42 VETI	10 UCCC
	6 EWPC	12 VSTL	18 HSSS
1 TILT	7 VIPC	13 V3RD	19 HLIN
2 VBOW	8 HIPC	14 V4TH	20 HSLN
3 SKEW	9 HKEY	15 HSBW	
4 HBOW	10 VKEY	16 HSKW	
			est. **
5 TBPC	11 VSBW	17 H3RD	

[Screen Cha	racter Circuit] Adjust	ment purpose To position the character display.
12. Characte	er Position Symptoincorre	om when Incorrect Character position
Measuring Instrument		Supply a VIDEO signal (Monscope). Press the "MENU" button on a remote hand unit.
Test Point		3. Press the buttons 2-3-5-7 in sequence. (The screen will change to the circuit adjustment mode.)
Exit Trigger		4. Set the function to "HR" using the "AUDIO" button. 5. Using the "ADJUST" button, align so that the widths for
Measurement range		A and B are equal.
Input Signal	Standard RF Broadcast	
Input Terminal	Antenna A/B	
		HR 02



[Convergence	: Circuit]	Adjustment purpose To correct color misconvergence in RED, GREEN, and B		
14. Dynamic Convergence Symptom when Colors misconverged. incorrectly adjusted				
Measuring Instrument		Note: This adjustment must follow item 13 (Static Convergence). Dynamic convergence should not be attempted until the static convergence has been properly adjusted. (including centering adjustment, if required).	-	
Test Point		Cover the RED or BLUE lens with a lens cap, and adjust the color convergence in GREEN and RED or in GREEN and BLUE.		
Exit Trigger		Supply a VIDEO signal (crosshatch). Press the "MENU" button on a remote hand unit.		
Measurement Range		3. Press the numerical buttons 2-3-5-9 in sequence to change the screen to the adjustment mode.		
Input Signal	VIDEO signal (Crosshatch)	4. Adjust the convergence according to the steps described below: a. Press the "VIDEO" button to select a specific adjustment item. b. Press the "ADJUST UP/DOWN button to change adjustment data.		
Input Terminal	VIDEO IN termina	c. Press "ENTER" to switch between RED and BLUE. Note: The newly entered data is automatically recorded.		

Adjustment Item		Description	
No.	Abbreviation		
00	HSTA	Red Horizontal Position	
01	VSTA	Red Vertical Position	
30	HSTA	Blue Horizontal	
31	VSTA	Blue Vertical Position	

Table A

- Press the numerical buttons 2-3-5-9 in sequence to change the screen to the adjustment mode.
- Adjust the convergence according to the steps described below:
 - a. Press the "VIDEO" button to select a specific adjustment item.
 - b. Press the "ADJUST UP/DOWN button to change adjustment data.
 - c. Press "ENTER" to switch between RED and BLUE.


- Display a red raster and a blue raster. Confirm no black or bright horizontal line appears on the middle of the screen. If a line appears, set the data of the adjustment item "56 DA42" so that the line disappears.
- Confirm no misconvergence occurs at the center of the screen.

Use the following method to correct center screen misconvergence:

- a. When in the dynamic convergence adjustment mode, select the items shown in Table A to converge RED and BLUE at the center of the screen.
- Press the "MENU" button twice to terminate the dynamic adjustment mode.

RED	BLUE	ITEM	ADJUSTMENT METHOD	PICTURE
2 TILT	32 TILT	Vertical Tilt	Merge horizontal center line with Green Line	
6 VWID	36 VWID	Vertical Height	Merge horizontal lines with GREEN lines	
7 VLIN	37 VLIN	Vertical Linearity	Merge horizontal lines with GREEN lines	
3 BOW	33 BOW	Vertical Bow	Merge horizontal center line with Green Line	
4 SKEW	34 SKEW	Skew	Merge vertical center line with Green Line	
5 HBOW	35 HBOW	Horizontal Bow	Merge vertical center line with Green Line	
8 HWID	38 HWID	Horizontal Width	Merge vertical lines with Green Line	

RED	BLUE	ITEM	ADJUSTMENT METHOD	PICTURE
9 HLIN	39 HLIN	Horizontal Linearity	Merge Vertical lines with Green Line	
15 HKLU	45 HKLU	Horizontal Keystone	Merge upper left vertical line with GREEN line	
17 VLIN	47 HKLL	Horizontal Keystone	Merge lower left vertical line with GREEN line	
19 HKRL	49 HKRL	Horizontal Keystone	Merge lower right vertical line with GREEN Line	
21 HKRU	51 HKRU	Horizontal Keystone	Merge upper right vertical line with GREEN Line	
14 VKLU	44 VKLU	Vertical Keystone	Merge upper left horizontal line with GREEN Line	
16 VKLL	46 VKLI	Vertical Keystone	Merge lower left horizontal line with GREEN Line	
18 VKRI	48 VKRL	Vertical Keystone	Merge lower right horizontal line with GREEN Line	
20 VKRU	50 VKRU	Vertical Keystone	Merge upper right horizontal line with GREEN Line	
10 HSDL	40 HSDL	Left Horizontal Side	Merge left Vertical line with Green Line	
11 HSDR	41 HSDR	Right Horizontal Side	Merge right Vertical line with Green Line	
22 LHBW	52 LHBW	Horizontal Sloping Ends	Merge upper and lower left vertical line with GREEN Line	
23 RHBW	53 RHBW	Horizontal Sloping Ends	Merge upper and lower right vertical line with GREEN Line	
24 LVBW	53 LVBW	Vertical Sloping Ends	Merge upper and lower left horizontalal line with GREEN Line	
25 RVBW	55 RVBW	Vertical Sloping Ends	Merge upper and lower right horizontalal line with GREEN Line	
12 SLIN	12 SLIN	Horizontal Width at the Middle (1)	Merge Vertical lines with Green Line	
13 CLIN	39 HLIN	Horizontal linearity at the Middle (2)	Merge Vertical lines with Green Line	



[PIP Circuit] 16. PIP Chroma Gain		Adjustment purpose	To set the color level between main and sub picture.	
		Symptom when incorrectly adjusted	Different color level between main and sub picture.	
Measuring Instrument Oscilloscope		II	neat the set for one minute or more. ply a VIDEO signal (color bar).	

3.

7.

8.

9.

10.

TP63 (pin 5 of IC7001) Test Point Exit Trigger Division 20mV Measurement Time 10us range VIDEO signal (Color Bar) Input Signal VIDEO IN terminal Input Terminal

- 2. Press the "MENU" button on a remote hand unit.
 - Press the numerical buttons 2-3-5-7 in sequence to change the screen to the circuit adjustment mode.
- Set the adjustment function to "PIP" by pressing the "AUDIO" button. 4.
- Set all the items in adjustment function "PIP" to the initial data value 5. (refer to page 21) using the "VIDEO and AUDIO" button.
- Observe the waveform at TP63 (pin 5 of IC7001). 6.
 - Select adjustment item "1 COLOR" using the "VIDEO" button.
 - Set the adjustment data so that the chroma signal amplitude of sub picture is 90 \pm 5% of main picture using the "ADJUST" button (Fig.7).

Press the "ENTER" to write the adjustment data into memory.

Press the "MENU" button twice to terminate the circuit adjustment mode.

Adjustment item 17 (PIP Sub Tint) must be performed Note: immediately after this adjustment.





Fig. 7

PCB-PIP/APT (COMPONENT SIDE)



[PIP Circuit]	Adjustment purpose Symptom when incorrectly adjusted			
17. PIP Sub Tint				
Measuring Instrument			Note:	Preheat This adju
Test Point			1. 2.	Supply a Activate I
Exit Trigger			3.	picture so Press the
Measurement range			4.	Press the
Input Signal	VIDEO signal (Color Bar)		5. 6.	Set the a
Input Terminal	VIDEO IN terminal		7.	Set the a in the ma
			8	Press the

the set for one minute or more.

ustment must follow item 16 (PIP Chroma Gain)

- VIDEO signal (color bar).
- PIP and display the same picture on main screen and sub creen.

To obtain the same hue in the main and sub picture.

Different hue between the main and sub picture, and color smear.

- e "MENU" button on a remote hand unit.
- e numerical buttons 2-3-5-7 in sequence to change the o the circuit adjustment mode.
- adjustment function to "PIP" by pressing the "AUDIO" button.
- djustment item "2 TINT" using the "VIDEO" button.
- adjustment data so that the sub picture corresponds to the hue ain picture using the "ADJUST" button.
- Press the "ENTER" to write the adjustment data into memory.
- 9 Press the "MENU" button twice to terminate the circuit adjustment mode.

[PIP Circu	Adjustment purpose				
18. PIP Contrast		Symptom when incorrectly adjusted			
Measuring Instrument	Oscilloscope		1.	Apply C	
Test Point	TP-62		2.	Using the the PIP	
Exit Trigger			3. 4.	Connec Synchro	
Measurement range			5.	figure {	
Input Signal	VIDEO (Color Bars)		6.	Press ti	
Input Terminal	VIDEO IN terminal		7. 8.	Select t Adjust i	


Apply Color Bar signal to External Input and select this image on both the Main and PIP pictures.


To obtain the proper contrast ratio in the sub picture.

- 2. Using the PIP position button on a remote hand unit, adjust to place the PIP window as shown in figure 8.
- Connect Oscilloscope probe to TP-62 and observe the waveform. 3.
- Synchronize the waveform on the Oscilloscope as shown in

Sub picture too light or too dark.

- Press the "MENU" button on a remote hand unit. 5.
- Press the numerical buttons 2-3-5-7 in sequence to enter the circuit adjustment mode.
- Select the "PIP" function using the "AUDIO" button. 7.
 - Adjust item "0 CONT" using the "ADJUST UP/DOWN" buttons to obtain the waveform ratio shown in figure 7 (Adjustment #16). PIP amplitude should be equal to 90 \pm 5% of Main picture.
 - Press the "ENTER" button to write the adjustment data into memory.
 - Press the "MENU" button twice to terminate the circuit adjustment mode.





CHIP PARTS REPLACEMENT


Some resistors, shorting jumpers (0 Ohm resistors), ceramic capacitors, transistors and diodes are chip parts. The following precautions should be taken when replacing these parts.

CAUTIONS:

- 1. Use a fine tipped, well insulated soldering iron (approximately 30 watts), and tweezers.
- 2. Melt the solder and remove the chip parts carefully so as not to tear the copper foil from the printed circuit board.
- 3. Discard removed chips; do not reuse them.
- 4. Do not apply heat for more than 3 (three)seconds to new chip parts.
- 5. Avoid using a rubbing stroke when soldering.
- 6. Take care not to scratch, or damage the chip parts when soldering.
- 7. Supplementary cementing is not required


1. Removal of Chip Parts (Resistors, Capacitors, etc)

- A. Grasp the part with tweezers. Melt the solder at both sides alternately and remove one side of the part with a twisting motion.
- B. Melt the solder at the other side and remove the part.




2. Removal of Chip Parts (Transistors)

- A. Melt the solder of one lead and lift the side of that lead upward.
- B. Simultaneously melt the solder of the other two leads and lift the part from the PCB.



3. Replacement

- A. Presolder the contact points on the circuit pattern.
- B. Press the part downward with tweezers and apply the soldering iron as shown



2. Electrical Parts and Others

A. Model: VS-45501/VS-45502/VS-45501A/VS-50501/VS-50502/VS-50501A

In order to expedite delivery of replacement parts orders, specify the following:

- 1. Model Number/Serial Number
- 2. Part Number and description
- 3. Quantity

Note: Unless complete information is supplied, delay in processing of orders will result.

B. Symbol

The electrical parts with shading are critical components, and the parts with * are warranty return items.

: Critical Components

*

: Warranty Items

MARK	В	С	D	F	G	J	K
Tolerance %	<u>+</u> 0.1	<u>+</u> 0.25	<u>+</u> 0.5	<u>+</u> 1	<u>+</u> 2	<u>+</u> 5	<u>+</u> 10

MARK	М	N	٧	Х	Z	Р	Q
Tolerance %	<u>+</u> 20	<u>+</u> 30	+10 -10	+40 - 20	+80 - 20	+100 - 0	+30 -10

MARK	В	С	D	F	G
Tolerance (ρF)	<u>+</u> 0.1	<u>+</u> 0.25	<u>+</u> 0.5	<u>+</u> 1	<u>+</u> 2

C. Abbreviation

[45501]	VS-45501
[45502]	VS-45502
[45501A]	VS-45501A
[50501]	VS-50501
[50502]	VS-50502
[50501A]	VS-50501A

SYMBO NO.	L PARTS NO.	PARTS NAME	DESCRIPTION	SYMBO NO.	L PARTS NO.	PARTS NAME	DESC	RIPTION
	TUBES			IC903	266P932O10	IC		AN7805
*	251C083O10	ASSY-CRT	RED-MONOCHROME 50501 50502		TRANSISTO	RS		
•	251C083O20	ASSY-CRT	GREEN-MONOCHROME 50501 50502	Q 100 Q 101	260P560O40 260P560O40			2SA933S-S 2SA933S-S
*	251C083O30	ASSY-CRT	BLUE-MONOCHROME 50501	Q 102	260P560O40	TRANSISTOR		2SA933S-S
	0540004040	ACOV ODT	50502 RED-MONOCHROME 50501A	Q 103		TRANSISTOR		2SC1740S-S
	251C091O10	and the second second		Q 104		TRANSISTOR		2SA933S-S
	251C091O20	and the second second	GREEN-MONOCHROME 50501A BLUE-MONOCHROME 50501A	Q 105		TRANSISTOR		2SA933S-S 2SA933S-S
	251C091O30		RED-MONOCHROME 45501	Q 106		TRANSISTOR		2SC1740S-S
	251C083O40	ASST-CRI	45502	Q 107		TRANSISTOR		2SC1740S-S
	05400000050	ACCV CDT	GREEN-MONOCHROME 45501	Q 109		TRANSISTOR		2SC1740S-S
	251C083O50	A551-CK1	45502	Q 110		TRANSISTOR		
	0540000000	ACCV COT		Q 2H04		TRANSISTOR		2\$C1740\$-\$
	251C083O60	ASSY-CKI	BLUE-MONOCHROME 45501 45502	Q 2H05		TRANSISTOR		2SC1740S-S 2SC1740S-S
. * *	0540004040	ACCV COT	RED-MONOCHROME 45501A	Q 2H06		TRANSISTOR		2SC1740S-S
	251C091O40	ASSY-CRT		Q 2H07		TRANSISTOR		
	251C091O50		GREEN-MONOCHROME 45501A BLUE-MONOCHROME 45501A	Q 2H08		TRANSISTOR		2SC1740S-S 2SC1740S-S
	251C091O60	ASSY-CRT	BLUE-MONOCHROME 45501A	Q 2H09		TRANSISTOR		2SA933S-S
1 1 N	INTECDATED	CIRCUITS		Q 2H10		TRANSISTOR TRANSISTOR		2SA933S-S
	INTEGRATED	CIRCUITS	•	Q 2H11				2SA933S-S
10000	0700047000	10	CXA2095S	Q 2H12		TRANSISTOR		2SC1740S-S
IC200	270P347O30 274P596O20		T90A13N	Q 2K0		TRANSISTOR		2SC1740S-E
IC2001			MM1031XS	Q 2030		TRANSISTOR		2SC1740S-E
IC2002	272P658O10		AN7809F	Q 2040		TRANSISTOR		
IC203	270P210O10		PA0057A	Q 2050		TRANSISTOR		2SC1740S-E
IC204	270P204O10			Q 2051		TRANSISTOR		2SC1740S-E
IC3A1	272P440O10		LA4282	Q 2052		TRANSISTOR		2SC1740S-E
IC3E1	270P467O10		TDA9855 LA7845	Q 206		TRANSISTOR		2SC1740S-S
IC401	270P064O20		UPC4570HA	Q 208		TRANSISTOR		2SC1740S-S 2SC1740S-S
IC5A00	272P106O30 266P154O10		UPC393C	Q 209		TRANSISTOR TRANSISTOR		2SA933S-S
IC5A01	274P762O90		M37270EFSP	Q 210				2SC1740S-S
1C700	275P039O20		M65617SP-A	Q 211		TRANSISTOR		2SC1740S-S
IC7001	273P039O20 272P761O10		MM1041XS	Q 212		TRANSISTOR		2SC1740S-S
IC7002	272P761010 272P658010		MM1031XS	Q 213		TRANSISTOR TRANSISTOR		2SC1740S-S
IC7003	272P656010 270P465010		NJM317	Q 214				2SC1740S-S
IC7004	274P333O10		24C04A*P	Q 215	260P559O30			2SA933S-S
IC701	266P130O30		PST520E	Q 216	260P560O40 260P559O30			2SC1740S-S
1C702			M38123E6SP	Q 217				2SC2229-Y
IC703	275P040O90		HD74HC32P	Q 220	260P385O20			
IC705	263P265O10 274P333O10		24C04A*P	Q 221	260P385O20 260P385O20			2SC2229-Y 2SC2229-Y
IC706 IC7601	274P333010 270P321O20		CXA1855S	Q 222	260P385020 260P560O40			2SA933S-S
1C8C00	266P154O10		UPC393C	Q 224	260P559O30			2SC1740S-S
IC8C00	270P202O10		CM0001AS	Q 225		TRANSISTOR		2SC1740S-S
IC8E00	270P202O10 270P202O10		CM0001AS	Q 3A1 Q 3A2		TRANSISTOR		2SC1740S-S
IC8E00	270P202010 272P106O20		UPC4574C	Q 3A2		TRANSISTOR		2SC1740S-S
IC8G00	272P100020 270P357O10		DM0002B	0 244		TRANSISTOR		2SA933S-S
IC8W00	267P077O20		STEADY DOD 252	11 0 0004		TRANSISTOR		2SC1740S-S
1C8W00	267P077O20		STK391-020 - 119	11		TRANSISTOR		UN4112 /2
IC8W01	267P077O20		STK391-020	Q 3E02 Q 3E03		TRANSISTOR		DTC124ES
IC800	270P203O20		M52336ASP	Q 3E03		TRANSISTOR		2SC1740S-S
IC800	274P713O10		CD0006BD	Q 5A00		TRANSISTOR		2SD2349
IC9A00	274P713010 270P466020		KIA7809PI	Q 5A00 Q 5A01	e e e e e e e e e e e e e e e e e e e	TRANSISTOR	1,21	2SC2482
IC9A00	270P466O20 270P466O10		KIA7805PI	1 1		TRANSISTOR		2SD2349
IC9A01	270P466O10 270P466O30		KIA7812PI	Q 5A02		TRANSISTOR		2SC1740S-E
1			KIA7805PI	Q 5A03				2SC1740S-E 2SC1740S-E
IC9A12	270P466O10		STR-M6811	Q 5A04		TRANSISTOR		
IC900	267P129O10		SE130N	Q 5A05		TRANSISTOR		2SC1740S-S
IC901	267P126O10		M5237L	Q 5A06		TRANSISTOR		2SA933S-S 2SC2482
IC902	272P240O10	10	J C Z C IVI	Q 5A07	2602422010	TRANSISTOR		2002402

NO.	OL PART NO.	S PARTS NAME	DESCRIPTION	SYMBO NO.	OL PARTS NO.	PARTS NAME	DESCRIPTIO	N .
Q 5A08	260P420O20	TRANSISTOR	2SC2073-B,C	Q 800	260P559O30	TRANSISTOR	2SC1740S-S	
Q 5H03	260P559O50	TRANSISTOR	2SC1740S-E	Q 9A00	260P646O10	TRANSISTOR	2SC1845-F,E	
Q 5H04	260P559O50	TRANSISTOR	2SC1740S-E	Q 900	260P559O50	TRANSISTOR	2SC1740S-E	
Q 5H05	260P559O50	TRANSISTOR	2SC1740S-E	Q 904	260P652O10	TRANSISTOR	2SA1725	
Q 5H06	260P559O50	TRANSISTOR	2SC1740S-E					
Q 5H07	260P559O50	TRANSISTOR	2SC1740S-E	- []	DIODES			
Q 5H08	260P559O50	TRANSISTOR	2SC1740S-E					
Q 5H09	260P559O50	TRANSISTOR	2SC1740S-E					
Q 5H10		TRANSISTOR	2SA933S-S	D 100	264P502O10	DIODE	HZ5ALL	
Q 5H11		TRANSISTOR	2SB940A-P	D 101	264P502O10		HZ5ALL	
Q 5H12		TRANSISTOR	2SD1264A-P	D 102	264P488O20		RD13FB1	
Q 5H13		TRANSISTOR	2SC1740S-E	D 104	264P470O40		RD33EB1/2	
Q 5H14		TRANSISTOR	2SC1740S-S	D 2H00	264P045O40		1S2471OM	
Q 5K00		TRANSISTOR	2SC4636	D 210	264P486O50		RD9.1FB2	
Q 5K01		TRANSISTOR	2\$C4636	D 211	264P045O40		1S2471OM	
Q 5K02		TRANSISTOR	2SC1740S-E	D 216	264P483O70		RD5.1FB1	
Q 5K02		TRANSISTOR	2SA933S-S	D 217	264P502O20		HZ5BLL	
2 5K04		TRANSISTOR	2SA9335-S 2SC1740S-E	D 217	264P045O40		1S2471OM	
2 6B0		TRANSISTOR	2SC1740S-E 2SC3271F-N,P	D 218	264P045O40 264P045O40		1S24710M 1S24710M	
			•					
Q 6B1		TRANSISTOR	2SA1321	D 220	264P483O80		RD5.1FB2	
Q 6B2		TRANSISTOR	2SC3334	D 221	264P045O40		1S2471OM	
Q 6G0		TRANSISTOR	2SC3271F-N,P	D 222	264P045O40		1S2471OM	
Q 6G1		TRANSISTOR	2SA1321	D 223	264P045O40		1S2471OM	
0 6G2		TRANSISTOR	2SC3334	D 224	264P045O40		1S2471OM	
0 6G5		TRANSISTOR	2SA933S-S	D 225	264P045O40		1S2471OM	
0 6R0		TRANSISTOR	2SC3271F-N,P	D 226	264P501O50		HZ3BLL	
0 6R1	260P469O30	TRANSISTOR	2SA1321	D 227	264P502O30		HZ5CLL	
0 6R2	260P307O20	TRANSISTOR	2SC3334	D 228	264P045O40	DIODE	1S2471OM	
7A00	260P559O30	TRANSISTOR	2SC1740S-S	D 229	264P045O40	DIODE	1S2471OM	
7A01	260P560O40	TRANSISTOR	2SA933S-S	D 230	264P045O40	DIODE	1\$2471OM	
7C00	260P559O30	TRANSISTOR	2SC1740S-S	D 3A3	264P501O40	DIODE	HZ3ALL	
7C10	260P559O30	TRANSISTOR	2SC1740S-S	D 3A4	264P045O40	DIODE	1S2471OM	
7000	260P559O30	TRANSISTOR	2SC1740S-S	D 3A5	264P045O40	DIODE	1S2471OM	
7006	260P559O30	TRANSISTOR	2SC1740S-S	D 3A6	264P045O40	DIODE	1S2471OM	
7007	260P559O30	TRANSISTOR	2SC1740S-S	D 3A7	264P045O40	DIODE	1S2471OM	
7008	260P559O30	TRANSISTOR	2SC1740S-S	D 3E00	264P045O40	DIODE	1S2471OM	
701	260P559O30	TRANSISTOR	2SC1740S-S	D 401	264D056O20		ERB12-02RK/3	
7011		TRANSISTOR	2SC1740S-S	D 402	264D056O20		ERB12-02RK/3	
7013		TRANSISTOR	2SC1740S-S	D 403	264D056O20		ERB12-02RK/3	
7014		TRANSISTOR	2SC1740S-S	D 5A00	264P045O40		1S2471OM	
7016		TRANSISTOR	2SC1740S-S	D 5A02	264P045O40		1S2471OM	
7017		TRANSISTOR	2SA933S-S	D 5A02	264P045O40		1S2471OM	
7018		TRANSISTOR	2SA933S-S	D 5A04	264P045O40		1S2471OM	
7019		TRANSISTOR	2SC1740S-S	D 5A04	264P045O40		1S2471OM	
7019		TRANSISTOR	2SA933S-S	D 5A06	264P045O40		1S2471OM 1S2471OM	
			2SC1740S-S	D 5A07			**	£
704 705		TRANSISTOR		11	264P244O30 264P045O40		HZT22-02	
		TRANSISTOR	2SA933S-S	D 5A11	264P469O70		1S2471OM	
706		TRANSISTOR	2SC1740S-S	D 5A20			RD27EB4/2	
708		TRANSISTOR	2SC1740S-S	D 5A21	264P045O40		1S2471OM	
709		TRANSISTOR	2\$A933S-S	D 5A22	264P045O40		1S2471OM	
710		TRANSISTOR	2SA933S-S	D 5A23	264P045O40		1S2471OM	
711		TRANSISTOR	2SA933S-S	D 5H00	264P045O40		1S2471OM	
712		TRANSISTOR	2SC1740S-S	D 5H01	264P045O40		1S2471OM	
713	260P560O40	TRANSISTOR	2SA933S-S	D 5H02	264P045O40		1S2471OM	
714	260P559O30	TRANSISTOR	2SC1740S-S	D 5H03	264D056O20		ERB12-02RK/3	
7601	260P559O30	TRANSISTOR	2SC1740S-S	D 5H04	264D056O20	DIODE	ERB12-02RK/3	
7602		TRANSISTOR	2SC1740S-S	D 5H09	264P045O40		1S2471OM	
7603		TRANSISTOR	2SA933S-S	D 5K01	264P528O30		RP 1H	
		TRANSISTOR	2SC1740S-S	D 5K02	264P543O10		EG01	
7670	ZUUF DOMEANI			11 5 5.102				
7670 7671		TRANSISTOR	2SC1740S-S	D 5K03	264P543O10	DIODE	EG01	

SYMBOL NO.	PARTS NO.	PARTS NAME	DESCRIPTION	SYMBOI NO.	PARTS NO.	PARTS NAME	DESCRIPTION
D 6B0	264P045O40	DIODE	1S2471OM	D 910	264P722O10	DIODE	SF64
	264P045O40		1S2471OM		264P724O10		STF14
	264P045O40		1S2471OM		264P722O10		SF64
	264P045O40		1S24710M		264P718O10		FR155
	264P045O40		1S2471OM				
	264P045O40		1S2471OM		FILTERS		
	264P457O80		RD3.3EB1				
	264P212O20	LED	LN31GPH	CF200	299P128O10	CERAMIC-OSC	CSB500F2
	264P045O40	DIODE	1S2471OM				
		DIODE	1S2471OM		DELAY LINES		
D 701	264P486O20	DIODE	RD8.2FB3				
	264P483O70		RD5.1FB1	DL201	337P134O10	DELAY-LINE	SDL-4256
	264P483O70	DIODE	RD5.1FB1	DL5H01	337P147O20	DELAY-LINE	
	264P483O70	DIODE	RD5.1FB1	DL5H02	337P147O20	DELAY-LINE	
D 706	264P483O70	DIODE	RD5.1FB1				
	264P483O70		RD5.1FB1		COILS		
	264P483O70		RD5.1FB1				and the second second
		DIODE	RD5.1FB1	1 1	330P209O40	DEFLECTION YOKE	VZ4-7-90
		DIODE	1S2471OM		338P046O10	CPM-ASSY	DBV4001M
	264P045O40	DIODE	1S2471OM	L 100	325C111O30	COIL-PEAKING	10MH-K
	264P045O40	DIODE	1S2471OM	L 101	325C111O30	COIL-PEAKING	10MH-K
	264P483O70		RD5.1FB1	L 102	325C111O30	COIL-PEAKING	10MH-K
	264D056O20		ERB12-02RK/3	L 103	325C111O30	COIL-PEAKING	10MH-K
	264P483O70		RD5.1FB1	L 104	325C111O30	COIL-PEAKING	10MH-K
	264P483O70		RD5.1FB1	L 105	325C168O70	COIL-PEAKING	1000MH-J
	264P483O70		RD5.1FB1	L 106	325C111O30	COIL-PEAKING	10MH-K
	264P483O70		RD5.1FB1	L 107	325C111O30	COIL-PEAKING	10MH-K
	264P483O70		RD5.1FB1	L 108	325C111O30	COIL-PEAKING	10MH-K
	264P483O70		RD5.1FB1	L 109	325C121O30	COIL-PEAKING	10MH-K
	264P483O70		RD5.1FB1	L 110	325C111O30	COIL-PEAKING	10MH-K
	264P045O40		1S2471OM	L 111	325C168O70	COIL-PEAKING	1000MH-J
	264D056O20		ERB12-02RK/3	L 112	325C111O30	COIL-PEAKING	10MH-K
	264P045O40		1S2471OM	L 201	325C121O30	COIL-PEAKING	10MH-K
	264P045O40		1S2471OM	L 2010	325C121O30	COIL-PEAKING	10MH-K
	264P485O60		RD7.5FB2	L 2011	325C121O30	COIL-PEAKING	10MH-K
	264P485O60		RD7.5FB2	L 2012	325C121O30	COIL-PEAKING	10MH-K
	264P485O60		RD7.5FB2	L 2031	325C121O80	COIL-PEAKING	27MH-K
	264P486O60	DIODE	RD9.1FB3	L 2040	325C121O80	COIL-PEAKING	27MH-K
	264P486O60		RD9.1FB3	L 2050	325C121O80	COIL-PEAKING	27MH-K
	264P045O40		1S2471OM	L 2069	325C121O30	COIL-PEAKING	10MH-K
	264P045O40		1S2471OM	L 211	325C122O50	COIL-PEAKING	100MH-K
	264P486O60		RD9.1FB3	L 212	325C121O30	COIL-PEAKING	10MH-K
1	264P486O60	DIODE	RD9.1FB3	L 214	325C166O70	COIL-PEAKING	22MH-J
	264P045O40	DIODE	1S2471OM	L 215	325C121O90	COIL-PEAKING	33MH-K
I	264P425O10	DIODE	ISS88	L 3F01	325C111O30	COIL-PEAKING	10MH-K
D 800	264P483O80	DIODE	RD5.1FB2	L 401	321C130O10	COIL-RF	2.0MH +-15%
D 9A00	264P718O20	DIODE	FR156	L 411	325C401O30	COIL-PEAKING	10MH-J
	264P720O10	DIODE	KBP202G	L 412	411P001O10	LEAD-FERRITE	
	264P470O80		EQA02-32C/2	L 5A00	351P156O20	COIL-CHOKE	YT-4361-1 2.4
	264P045O40		1S2471OM	L 5A01	351P156O10	COIL-CHOKE	YT-4360-1 3.1
D 9A04	264P045O40		1S2471OM	L 5A02	333P040O60	COIL-HORIZ-LINEA	RITY
	264P045O40		1S2471OM	L 5A03	411P001O10	LEAD-FERRITE	
	264P825O10		ERA15-02	L 5A04	411P001O10	LEAD-FERRITE	
	264P721O10		TS6B06G	L 5A05	321C030O70	COIL-RF	3.3MH-K
	264P487O80		RD12FB2	L 5A06	411P001O10	LEAD-FERRITE	
	264P522O10		RU 1P	L 5H00	411D009O20	CORE-FERRITE	
	264P724O10		STF14	L 5K00	411P001O40	LEAD-FERRITE	
	264P578O10		RG 2A	L 6B0	325C402O20	COIL-PEAKING	56MH-J
	264P588O10		FML-G16S	L 6B1	325C402O20	COIL-PEAKING	56MH-J
			SF64	L 6G0		COIL-PEAKING	56MH-J
D 908	264P722O10	DIODE	51 04	1 5000	0200 102020	0012 1 2/111110	OOMIT O

MODEL: VS-45501/VS-45502/VS-45501A/VS-50501/VS-50502/VS-50501A


SYMB NO.		S PARTS NAME	DESCRIPTION	SYMBO NO.	OL PART	S PARTS NAME	DESCRIPTION
L 6R0		COIL-PEAKING	56MH-J	T 5A01	336P031O10	COIL-HORIZ-DRI	VE
_ 6R1		COIL-PEAKING	56MH-J	T 5A02	336P031O10	COIL-HORIZ-DRI	VE
7000	325C110O50	COIL-PEAKING	2.2MH-K	• • • • • •	333. 33.3.3	001217011125111	-
7001	325C110O30	COIL-PEAKING	1.5MH-K				
7002	325C121O30	COIL-PEAKING	10MH-K		TRANSFOR	MEDO	
7003		COIL-PEAKING	10MH-K	- 11	INANGFOR	INEKS	
7004		COIL-PEAKING	10MH-K	- 11 -		,	
7006		COIL-PEAKING	10MH-K	T 5400	0.400400000	TRANS SIRE RO	_
7007		COIL-PEAKING	10MH-K	T 5A00		TRANS-SIDE-PC	
. 7008		COIL-PEAKING	10MH-K	T 5A03		TRANS-FLYBACK	
. 701		COIL-PEAKING	10MH-K	T 9A00		TRANS-POWER	
. 702		COIL-PEAKING		T 900		TRANS-POWER	EE-42
. 702			10MH-K	T 901	350P405050	TRANS-POWER	
		COIL-PEAKING	10MH-K				
704		COIL-PEAKING	10MH-K	1}	VARIABLE	RESISTORS	
705		COIL-PEAKING	10MH-K				
706		COIL-PEAKING	10MH-K	RV900	265P100O10	VARISTOR	ERZV10D271 /2
707		COIL-PEAKING	3.3MH-J	- 11	129P059O30	VR-FOCUS	MHF116-50
708		COIL-PEAKING	5.6MH-J			-	· -,
709		COIL-PEAKING	10MH-K	H	RESISTORS	3	
710	325C165O70	COIL-PEAKING	3.3MH-J		3.2.0.0	-	
711	325C166O30	COIL-PEAKING	10MH-J	R 106	103P331080	R-C	1/4W 270OHM -J
714	321C114O70	COIL-RF	6800MH-J	R 3B8	103P378O40	· · · -	1/4W 2.2 OHM -J
715		COIL-PEAKING	10MH-K	R 3B9	103P378O40		
716		COIL-PEAKING	10MH-K	16			1/4W 2.2 OHM -J
7601		COIL-PEAKING	10MH-J	R5A-01	103C190O10		3W 10 OHM - J
7602		COIL-PEAKING	10MH-J	R5A02	103P712O51		1/4W 1K
77A1		COIL-PEAKING		R5A03	103P712O81		1/4W 1.8K-J
	321C031O40		10MH-K	R5A04	103C190O90		3W 47 OHM - J
8D01			10MH-K	R5A05	103C190O70		3W 33 OHM - J
8E01	321C031O40		10MH-K	R5A07	103P712PO51	R-C	1/4W 1K - J
8F01	321C031O40		10MH-K	R5A08	103P714O41	R-C	1/4W 39K - J
8F02	321C031O40		10MH-K	R5A09	103P712O51	R-C	1/4W 1K - J
8W01	321C031O40		10MH-K	R 5A10	109D074O20	R-CE-M	5W 6.8K-K/J
8W02	321C031O40		10MH-K	R5A11	10P463O31	R-M	1/4W 2.2K - F
8W03	321C031O40	COIL-RF	10MH-K	R5A13	103P712O71		1/4W 1.5K - J
8W04	321C031O40	COIL-RF	10MH-K	R5A17	103P713O51	and the second s	1/4W 6.8K - J
8W05	321C031O40	COIL-RF	10MH-K	R5A18	103P713O61		1/4W 8.2K - J
8W06	321C031O40	COIL-RF	10MH-K	R5A19	103P713O71	**	1/4W 10K - J
800	321C031O40	COIL-RF	10MH-K	R5A28	103P463O41		
802	321C031O40	COIL-RF	10MH-K	11			1/4W 2.4K - F
803	321C031O40		10MH-K	R5A29 R5A30	103P460O91 103P463O81		1/4W 22O OHM - F 1/4W 3.6K - F
900		LINE-FILTER	SS35V-30082	11			the state of the s
902	351P155O10		YT-4388-1	R5A40	101P101E31		1/4W 100 OHM - K
903	351P155O10		YT-4388-1	R5A45	103C391O50		3W 150 OHM - J
904	351P155O10		YT-4388-1	R 5A47	109D074O20		5W 6.8K-K/J
905	351P155O10			R 5A50	103P438O40		2W 2.2 OHM-K/J
905			YT-4388-1	R5A60	103P463O21	and the second second	1/4W 2K - F
	321C142O30		68MH-K 9X9.5	R5A71	103P714O41		1/4W 39K - J
806	321C142O30		68MH-K 9X9.5	R5A75	103P465O31		1/4W 15K - F
909		LEAD-FERRITE		R5A76	103P464O91		1/4W 10K - F
910		LEAD-FERRITE		R5A81	103P463O61	R-M	1/4W 3K - F
011		LEAD-FERRITE		R5A82	103P463O41	R-M	1/4W 2.4K - F
912		LEAD-FERRITE		R 5H02	103P378O00		1/4W 1.0 OHM -J
913		CORE-FERRITE		R 5K09	103P392O20		1/2W 560 OHM -J
914	411D009O20	CORE-FERRITE		1.1	103P390O60	the state of the s	1/2W 27 OHM -J
925	411D009O20	CORE-FERRITE		11	103P390O60		1/2W 27 OHM -J
2091	409P402O30	EMI-FILTER	FZ103N100	11	109D077O80		15W 0.56-K
2092	409P402O30		FZ103N100	11	109D077O80		
701	409P402O10		B101M100	11			15W 0.56-K
702	409P402O10		B101M100	11	102P107O30		2W 0.27-K
703	409P402O10		B101M100		102P106O80		2W 0.1-J
				R 918	109D094O30		7W 22K-K
704	409P402O10	FMI-FII I F P	B101M100	R 922	103P398O90		1/2W 5.6 OHM -J

SYMBOI NO.	PARTS NO.	PARTS NAME	DESC	CRIPTION	SYMB NO.	OL PARTS NO.	S PARTS NAME	DESCRIPTION
R 927	109D036030	R-COMP	1/2W	1.0M-K	-			
	109D036030		1/2W	1.0M-K		449C134O10	SOCKET-CRT	til er tærtig jalende
	109D030000		1/2W	1.5M-K	11	480P039O10	SPEAKER	A(102-118)FL-1
N 331	1030021070	IV-GOLID	1/211	11011111	AG5K00	224D019O40	AIR-GAP	2KV
	CAPACITORS	AND TRIM	MERS		AG900	224D019O40		2KV
	CAPACITORS	AND INIM	WILKS		F 900	283D060O20	The state of the s	S5A
					F 901	283D038O70		S4A
0.300	4000074050	CMDD	200V	0.33MF-J	F 902	283D038O70		S4A
	189P071O50		1600V	4300PF-J	K 900		RELAY-POWER	DJ12D1-0(M)
	172P172O70		200V	0.033MF-K	PC900		PHOTO-COUPLER	ON3161-R
	172P081O80			4300PF-J	PJ701		JACK-MICROPHONE	
	172P172O70	the state of the s	1600V	the second of the second of the second of	PJ7601		PIN JACK BOARD	3PIN
	172P330O71		50V	3300PF-J	PJ7602		JACK-BOARD	PINX6 & SX2
	172P170O90		1600V	4700PF-J	PJ79A0		JACK-BOARD	PINX3 & SX1
	172P170O90		1600V	4700PF-J	11	264P723O10		SFH310-3
and the second	189P081O60	and the second s	200V	0.15MF-J	PT7A00			ENG26104G
7	189P081O60		200V	0.15MF-J	TU101	295P420030		ENG26104G ENG26104G
	189P071O80			0.47MF-J	TU102		TUNER	3.5795MHZ
	72P262O51		50V	0.1MF-J	X 200		QUARTZ-CRYSTAL	
	154P264060		3.15KV	470P-K	X 3E1		CERAMIC-OSC	C5B503F58
C 5K00	172P171O60	C-M-PP	1600V	0.018MF-J	X 7000		QUARTZ-CRYSTAL	HC-49/U
	172P171060		1600V	0.018MF-J	X 701		QUARTZ-CRYSTAL	8.00MHZ
C 900	189P153O40	C-M-P-AC	AC250V	0.1MF-M	X 702		QUARTZ-CRYSTAL	6.30MHZ
	189P067O60	C-C-AC	B VA1	1000PF-M	Z 7706		UNIT-PREAMP	HC-437ME
	189P067O60		B VA1	1000PF-M	Z 900	283P039O20		SSFR 6.3A
	189P134O80		F VA1	2200PF-M	Z 901	283P039O20		SSFR 6.3A
	189P134O80		F VA1	2200PF-M	Z 902	283P030O90	FUSE	SSFR 4A
	189P134O80		F VA1	2200PF-M	Z 903	283P039O20		SSFR 6.3A
	189P134O80		F VA1	2200PF-M	Z 905	283P030O60		SSFR 2A
C 900	185D063O30		H180V	820MF-M 105C				
	185D063O30		H180V	820MF-M 105C	H			
C 900 C 917	185D063O30		H180V	470MF-M 105C	11			
	185D062O50		H50V	4700MF-M		PRINTED (CIRCUIT BOARDS	
C 920	185D062O50		H50V	4700MF-M				
C 928		C-ELE C-M-P-AC	AC250V	0.1MF-M	1 *	935D326O01	ASSY-PWB-AV	
C 931			AC230V AC125V	4700PF-M	*		ASSY-PWB-CONTR	OL
C 938	189P152O50				*		ASSY-PWB-CONV	50501
C 944	189P152O50		AC125V	4700PF-M	*		ASSY-PWB-CONV	45501
C 952	189P134O80		F VA1	2200PF-M	*		ASSY-PWB-CRT	
C 953	189P134O80	C-C-AC	F VA1	2200PF-M	,		ASSY-PWB-DBF	50501 W - 1374
				0DE 40DE			ASSY-PWB-DBF	45501 C18 116 26
VC7000	202P109O10	C-TRIMMER		3PF-10PF	*		ASSY-PWB-FRONT	45501 GLO - (17)
							ASSY-PWB-RONT ASSY-PWB-MAIN	50501
	SWITCHES							45501
					.		ASSY-PWB-MAIN	
S 7A00		SW-KEY-BOAR		1-1 H=4.3			ASSY-PWB-PIP/APT	
S 7A01	432P100O10	SW-KEY-BOAR	RD	1-1 H=4.3	[ASSY-PWB-PREAM	
S 7A02	432P100O10	SW-KEY-BOAF	RD	1-1 H=4.3	*		ASSY-PWB-SIGNAL	
S 7A03	432P100O10	SW-KEY-BOAF	RD	1-1 H=4.3	*		ASSY-PWB-SIGNAL	45501A
S 7A04		SW-KEY-BOAF		1-1 H=4.3	*	935D354O01	ASSY-PWB-SVM	
S 7A05		SW-KEY-BOAF		1-1 H=4.3				
S 7A06		SW-KEY-BOAF		1-1 H=4.3		MECHANICA	L PARTS	
S 7A07		SW-KEY-BOAF		1-1 H=4.3	H			
S 7A08		SW-KEY-BOAR		1-1 H=4.3		669D212O10	SCREW-TB-BIND	3X12 *10
TU 103	295P421O20			ENPE624		669D220O30	SCREW-TB	3X10 46LA005 *10
10 103	2001 42 TU2U	2111 7011					SCREW-TB	3X16 46LA005 *10
	MISCELLANI	Eous					SCREW-TB	4X12 46LA005 *10
	453B027O10	CAP-ANODE						
		CAP-ANODE		•				
	767D048O30			VS-50501				
1	767C048040	MIRROR		VS-45501	11			

MODEL: VS-45501/VS-45502/VS-45501A/VS-50501/VS-50502/VS-50501A

SYMBO NO.	OL PART NO.	S PARTS NAME	DESCRIPTION		MBOL NO.	PARTS NO.	S PARTS NAME	DESCRIPTION
	COSMETIC	PARTS			PACKING	PARTS	AND ACCESSOR	lies
	246C160O20	AC-POWER-CORD						
	740A365O10		50501		802B62001		PACKING CASE	45501
	740A383010		45501		802B620O3		PACKING CASE	50501
		FRAME-SCREEN	50501		829D176O		PACKING SHEET	45501/50501
		FRAME-SCREEN S	50501	3	802B61001		PACKING CASE	45501
		FRAME-SCREEN	45501	11	802B610O3		PACKING CASE	50501
		FRAME-SCREEN S	45501	4	831C060O		PACKING-BAG	45501/50501
		HOLDER-SCREEN	50501	5	829D126O		PACKING-SHEET	45501/50501
-	622D539O50		50501	6	802B63001		PACKING TRAY	45501
	622D673O10		50501	6	802B630O3		PACKING TRAY	50501
		BACK BOARD	50501	- 11	831D191O		PACKING-BAG	45501/50501
		HOLDER-SCREEN	45501		871D223O		IB	50501
	622D539020		45501	9	242D266O4		CABLE	PLUG-PLUG (3.5)
	622D673020		45501	10	290P080O2	20	REMOTE HAND UNIT	50501
	700C245080	BACK BOARD	45501					
	700C240O90	BACK BOARD	45501A					
	641D173O10	CLIP	AC-PWR-CORD					
	761C273O10	DOOR-CATCH	45501/50501					
	703B024O10		50501					
		COVER-FRONT	50501					
		PANEL-CONTROL	50501					
		PANEL-CONTROL	45501					
		GRILLE-SPEAKER	50501					
		GRILLE-SPEAKER	45501					
	490P138O10		45501/50501					
	490P138O20		45501/50501					
	490P138O30		45501/50501					
	490P154O10	SCREEN-LENTICULAR	45501/50501					
		LENS-FRESNEL	R 50501 50501					
		SCREEN-LENTICULAR						
		LENS-FRESNEL	45501					
		SCREEN CAP	45501/50501					
		SCREEN CAP	45501/50501					
	102/01/10/20	SORLEN OA	43301730301					
				П				
				- 11				

PACKAGING ITEMS



PAGE 44


LEAD DRESS

THE INNER WIRES ARE CLAMPED SO THAT THEY DO NOT COME CLOSE TO HEAT GENERATING OR HIGH VOLTAGE PARTS. AFTER SERVICING, ROUTE ALL WIRES IN THEIR ORIGINAL POSITIONS.


The Anode Lead Wires are routed so that no tension is applied to the Anode Caps. If the routes of the Anode Lead Wires are changed during service, return them to their original positions. Clamp the Lead Wires along the clamping path as shown in the figure below. Insure that the Lead Wires are not slack.

Note:

CAUTION:




[REAR VIEW]




PAGE 47


VZ4 CHASSSIS BLOCK DIAGRAM


POWER






VZ4 CHASSIS SIGNAL PATH DIAGRAM











A CONTRACTOR OF THE PARTY OF TH




211A002F1

Γ


.







D733 D734	0700	0700	0/30	0,700	טלאט ל	707	9726	0725	0.724	3/23	2270	17/0	0751	1770	9170	D718	77.70	10	215	ا ر ا	0714	0713	0710	0709	/0//	D/Uc	0 0	0704	0703	5070	0701	D3E00	ОЗАВ	UJA/	UJAC	00.40	: U3A4	000	1242 100/20	100 car	13A I	SCHOOL SCHOOL	USHCU	DS30	0229	0228	0227	0225	0224	0223	0220	0219	8120	0217	U216	11.20	0170	- C- C-	0.00	nino	0101	00:00	CL 200	No.	SYMBOL ADD	PC8-S1
0-5	2 - 2	4	- C	- 0		n-5	11	5-2	F-2	E-3	1 17) c	-5 0	F-5	<u>?</u>	E-2	C: 1-) — 4	- C		6-5	H-2	2-0	0-2	Z-0	1 2	= د د		<u>ت</u>	i -∴	F-3	17	j-7	. II	0-1	α α	- - - a	0	H-7	ر ا	-i-D	B-4	R-2	C-4	B-3	8-3	A-1	A-2	A-2	- 1	ස <u>-</u> ධ	C-3	C-3	B-3	A-3	1 1	1 1	- I	11	1 1	G-4 ·	S-2	B -,4	,	ADDRESS	G! IAL
PJ700	LC/U#	al∖	LC/UZ	10,01	1, 1701	7 5	1715	1714	L711	L710	L/US	1200	700	1 707	L706	L705	L/U4	L/03	700	702	701	L215	L214	11212	1211	1210				=	L110	L109	L 108	L10/	L 100	בו בו	101	107	- Ing	100	101	198		Cl ApJi	IC9A01	[C9A00	IC706	10705	IC703	IC702	IC701	IC700	IC3E1	IC3A1	IC204	10203	10200	10000		SONOO	D9A05	09A04	0736	727 NO.	SYMBOL	
8-9	7-7		1 1	- -		- ·	_	.r.	0-3	D-2	1-1	- G	5 1	2-2	<u>+</u>	G-1	5-	-		-	-	က	င်- ၅	C-7	A-4	2,0	, -	п : Л	H-4	<u>.</u>	<u>-</u> 5	<u>2</u>	6-5	J	5	4 4 ×	- 5		n -	† Į	1 1	F-5			A-7	8-,7	Ŧ-	1	E-5	1	0-3	H-2	6-3	I-7		1 1	1 1		- 1 1	20 0	: ب	- C	2 2		ADDRESS	
07001	1 NOO 1	0,10	5 0	1	071) i	0717	071:	0710	Q709	RC/17	00.00	0702	3765	10,72	03E03	U3EU2	USEU1	0 0	בין בי	CAFO	03A1	0314	02KO	Q2H12	11470	21.0	USHCU	52429	02H08	Q2H07	Q2H06	02H05	UZHU4	0222	12C0	7777	2 1	1000	USSU :	3 :	00.5	15.0	1120	0213	2:30	0211	0210	0209	0206	0110	0109	0107	0106	0105	0104	2010	20,000	0.50	0100	010	000	70/61	5 5	TOBW.S	
-4	ر ا		110			- I	1 [1	<u>E</u>	1 1	c2	- 1 - 1		E	5	ر- ا	<u>U-/</u>	1,1	1	1.7		-5	<u></u>	<u></u>	1-	ند - -	1 1	2	1	1 1	_{ම-2}		1	1 (1 1	1 G	- 1 1		- C	ıí	1	1 1		1	1	C-6	က တ	1 1	1 1	1	[-4	H-4	[-5	-5	H-4	1 1	ָּבֶּי בְּיִבְּיִבְּיִי	1 1		ירן הודי	1 1	F-5	מ		STMBOL ADDRESS	
												1	T			-																																						X702	X701	X3E1	X200		1010	COILLI	TII 101	10.0	TP11A	: <u>.</u>	SYMBOL	
																																					1										-			,				- 1	<u>ြ</u>	1	1 1		- 1	ב כ	2-2		T	ו	ADDRESS	3
()																																																																		
_																																																																		_


,








[4]	L401		K900	- (IC9A02		10902	10601	10001		[[542]]	105400	10±01		000	RCCDCE	ACC504	(B) 0503	1000	7 0000	10000 20000	F0900A		F 902	2000	1363	6003		D9A03	D9AG2	10WG1	10000	COAGO	09:4	6.63	7167	2 0	rain	2000	8060	0907	nana	2 0		กอกจ	0901	0000	D5A27	D5A23	DSACC	ומאטם	10750	05A20	05A11	05A09	05A08	USAU/	כטאכט	2 5	מאס מ	DSAD3	05A02	05A00	U4)U3	70+07	CCVC	0401		AG900	200	S CABOL	PCB-MA
A-2	B-2	1 1	8-6		8-4	1 (6-6	1 1	1.0	50 0	1 1	1	3-2 3-2	!	- 1	ادا	1	t t	1 1	- 1	-> ->	- 1		1 1	- 1	- A	1		A-7	1	2 0	> C	B	0-4	2-0	0) 4) 4		<u>-</u>	<u>.</u>	7-3	12	5 6	ה ה	20 0	 	อ-7	2-1	J-1	7-1			<u>-</u>	1 1	J-3	J-4	t i		- 1	5	, t	-1 -		1 1	2 0		۸-۵		8-8)	ADDRESS	
										1000	7905	Z903	2902	1067	100	7900		T900A	3 3		-5A02	15A02	15A02	IDACI	2 0	TSAOO		Q9A00	Q904	UNER	BONCP	2000	75A08	05A05	U5AU4	UDAUS	20,700	02.00	104701	Q5A00		חהחה		[1 2025	L914	L913	L911	T910	FOR		999	1.007	1.905	1.904	L903	7067	0067		51,00	5A05	L5A03	L5A02	10VG	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	ה מיני	L5A00	L412	L411	2	NO SAN SOL	
											1]	0-4	€-4	1 1	5 0	1		1 1	ני ו	- 1	H-7	1-4	<u>π</u> -3	1-J	- 1	1		1 1				- c	1 1	- 1	J-2	2-5	- 1	T I	-4	1		6-/	1			F-7	F-6	E-3	7-4	(- C) c	n-3	0-2	F-3	C-3	D-2	I-1	0.0) -	- הלים	±-5	Z-1	H-2	5-4) = . c	·	. [-4	B~1	A-3		ADDRESS	












































	Company of the second of the s
	PCB-PIP/APT SYMBOL ADDRESS ND. D7001 A-3 D7002 B-3 D7002 B-3 D201 D-1 IC201 D-1 IC202 D-1 IC202 B-1 IC7003 B-1 IC7003 B-1 IC7004 B-3 L7000 D-2 L7001 D-2 L7001 D-2 L7009 D-2 L7009 D-3 L7009 D-2 D201 D-1 D208 A-3 L7009 D-2 D201 D-1 D208 C-1 D209 D-3 D7000 D-3
LC2091 8-7 LC2092 8-7 LC2092 8-7 PJ7601 0-7 PJ7602 0-4 Q2050 8-4 Q2050 8-4 Q2052 C-4 Q7601 8-7 Q7602 8-7 Q7602 8-7 Q7603 8-6 Q7670 E-5 Q7670 F-5 Q7682 A-6	PCB-A/V SYMBOLLAGDRESS NO. D7601
1	PCB-CONVERGENCE SYMBOL ADDRESS NO. DB00 A-3 DBC01 C-3 DBC02 C-3 ICB00 B-3 ICB000 A-2 ICB000 A-2 ICB000 A-2 ICB000 B-2 ICB000 C-2 ICB000 C-2 ICB000 C-2 ICB000 C-3 ICB001 B-1 ICB002 A-1 ICB002 C-3 ICB003 C-3 ICB001 A-1 ICB002 C-3 ICB001 A-1 ICB002 C-3 ICB001 C-3 IC

The the continues by 1949 of the




?CB-SIGNAL


200 CXA2095S




'E1 TDA9855




IC700 M37270EFSP




703 M38123E6SP






IC204 PA0057A




PCB-A/V

IC2001 T90A13N




7601 CXA1855S




PCB-MAIN

IC401 LA7845




PCB-CONVERGENCE

IC800 M52336AS




PAGE 55

D00 CM0001AS




00 PM0002B




PCB-PIP

IC7001 M65617SP-A



B C D E F G H I

PCB-HF




① 1.5V p-p (H)

CONTENTS

PG.1....BLOCK DIAGRAM
PG.2....MAIN
PG.3....SIGNAL
PG.4....FS
PG.5....HF
PG.6....SVM
PG.7....AV/YCS
PG.8....PIP/APT
PG.9....CONV
PG.10...DBF, CONT-1, FRONT-1, PREAMP
CRT (R), CRT (G), CRT (B)

VS-45501 VS-45502 VS-45501A VS-50501 VS-50502 VS-50502A PCB-SVM





6 VS-45501 VS-45502 VS-45501A VS-50501 VS-50502 VS-50502A


6

CONTENTS

PG. 1....BLOCK DIAGRAM
PG. 2....MAIN
PG. 3....SIGNAL
PG. 4....FS
PG. 5....HF
PG. 6....SVM
PG. 7....AV/YCS
PG. 8....PIP/APT
PG. 9....CONV
PG.10...DBF, CONT-1, FRONT-1, PREAMP
CRT (R), CRT (G), CRT (B)







MODELS: VS-45501, VS-45502, VS-45502A VS-50501, VS-50502, VS-50502A

11

12

13

1. DC voltages were measured from points indicated to the circuit ground with a high-Z voltmeter.

16

- 2. Waveforms were taken with standard color bar signal3. TP13, etc. show Test Points

Δ	CAP.	ACI	TNF

Value	Not indicated			PF, for numbers more than 1 μF, for numbers less than 1	
Dielectric Strength	Not indicated :50V				
	Not indicated = ± 10%		± 10%	No tolerance is indicated for electrolytic capacitors and ± 20%	
Tolerance	J = ±	5%	- ()%	Q = $+ 30\%$ C = $\pm 0.25PF$ $- 10\%$ D = $\pm 0.5PF$ T = $+ 200\%$ F = $\pm 1PF$ $- 0\%$ G = $\pm 2PF$	
Туре	I	Parts except for chips	MFP MPP PS TAN or	icated: Ceramic capacitor Polyester capacitor Polypropylene film capacitor Aluminum electrolytic capacitor Twin film capacitor Semiconductor Ceramic capacitor Metalized paper Metalized plastic film capacitor Metalized polyester capacitor Polyester polypropylene film capacitor Styrol capacitor TANT : Tantalum capacitor Electrolytic capacitor Non polarized electrolytic capacitor	
	II	Chips ::	Not ind	icated : Ceramic capacitor chip : Electrolytic capacitor : Non polarized electrolytic capacitor chip	

5. RESISTORS

capacitor)

CH, SL, etc.

Value				
Wattage	Parts except for chips Chips	Not indicated = 1/4W or 1/6W Not indicated = 1/10W		
Tolerance	Not indicated D = ± 0.5% F = ± 1%	J = ± 5%		
Туре	Parts I except for chips	Not indicated: Carbon resistor S: Fixed composition resistor MB: Metal oxide film resistor (type B) CE: Cemented resistor W: Wire wound resistor M: Metal film resistor MPC: Metal plate cement resistor ME: Metal liner resistor		
	II Chip	Not indicated = Chip resistor		

: Temperature compensating types

6. This is a basic schematic diagram. Some sets may be subject to modification according to enginnering improvement.

SHADED COMPONENTS HAVE SPECIAL CHARACTERISTICS IMPORTANT TO SAFETY. BEFORE REPLACING ANY OF THESE COMPONENTS READ CAREFULLY THE PRODUCT SAFETY NOTICE IN THE SERVICE MANUAL. DO NOT DEGRADE THE SAFETY OF THE RECEIVERS THROUGH IMPROPER SERVICING.

SERVICE TECHNICIAN WARNING X--RADIATION PRECAUTION THIS PRODUCT INCLUDES CRITICAL ELECTRICAL AND MECHANICAL PARTS ESSENTIAL FOR X--RADIATION PROTECTION. TO AVOID POSSIBLE EXPOSURE TO X--RADIATION TAKE X--RADIATION PROTECTIVE MEASURES FOR PERSONNEL DURING SERVICING. SEE SERVICE INSTRUCTIONS FOR SPECIFIED REPLACEMENT PARTS AND SERVICE ADJUSTMENTS.



